



J4060-04-35X

4U60 35X 12G SAS JBOD
User's Manual

Table of Contents

Preface	i
Safety Instructions	ii
About This Manual	iv
Chapter 1. Product Features	1
1.1 Box Content.....	1
1.2 Specifications	2
1.3 Feature.....	2
Chapter 2. Hardware Setup	7
2.1 Top Cover	7
2.2 Disk Drive	8
2.2.1 Installing the 3.5" Hard Disk Drive	8
2.2.2 Removing the 3.5" HDD from the Tray	9
2.2.3 Removing and Installing the HDD Tray	10
2.3 Power Supply Unit Module.....	11
2.3.1 Installing the Power Supply Unit	11
2.3.2 Removing the Power Supply Unit	11
2.4 Fan Module	12
2.4.1 Installing the Fan	12
2.4.2 Removing the Fan	12
2.5 Expander Module.....	13
2.5.1 Installing the Expander	13
2.5.2 Removing the Expander	13
2.6 Slide Rail	14
2.7 Standard Cabling	17
2.7.1 Single expander JBOD and 1 host server with 1 HBA card	17
2.7.2 Dual expander JBOD and 1 host server with 2 HBA cards	17
2.7.3 Dual expander JBOD and 2 host servers with 1 HBA card each.....	18
2.8 Hardware Settings	19
2.8.1 Drive Backplane: 30 Bay	19
2.8.1.1 SAS PHY mapping	19
2.8.1.2 Placement	19
2.8.1.3 Connector.....	20
2.8.1.4 LED Indicator.....	23
2.8.2 Expander Backplane	25
2.8.2.1 Placement	25
2.8.2.2 Connector.....	26
2.8.2.3 LED Indicator.....	28
2.8.2.4 Jumper	30
2.8.3 Connect Board Backplane	32
2.8.3.1 Placement	32

2.8.3.2 Connector.....	32
Chapter 3 Expander Configuration Settings	33
3.1 Supported Configuration and Unsupported Feature	33
3.1.1 Support Multiple Host/Path Access	33
3.1.2 Unsupported Feature	33
3.2 SES Inband Features.....	34
3.2.1 SES Pages.....	34
3.2.2 SES Elements	34
3.2.3 Implementation on SES Pages.....	35
3.2.4 Implementation on SES Elements.....	38
3.2.5 SES Element Control Functions.....	45
3.2.6 How to update all firmware/MFG through in-band SES.....	51
3.3 Configure Serial Command Line Interface Functions	52
3.3.1 How to enable/disable T10 zoning	52
3.3.2 How to configure T10 zoning	52
3.3.3 How to get all revisions in AIC® SAS 12G Expander	54
3.3.4 How to configure enclosure address (HUB only)	54
3.3.5 How to configure standby timer for all disk drives (EDGE only)	54
3.3.6 How to configure wide port checker	55
3.3.7 How to power off/on all disk drives automatically	55
3.3.8 How to configure EDFB (EDGE only)	56
3.3.9 How to configure zone count (Hub only)	57
3.3.10 How to configure zoning of the wide port (HUB only)	62
3.3.11 How to configure zoning of the disk slot (EDGE only)	62
3.4 Vendor Specific Vital Product Data (VPD) Page	63
Chapter 4. BMC Configuration Settings	64
4.1 Login	64
4.2 Web UI.....	68
4.2.1 Introduction.....	68
4.2.2 Overview of the ASPEED AST2520 BMC	68
4.2.3 AIC BMC Features	68
4.2.4 Applicable or Supported Platforms.....	68
4.2.5 Log In to the Remote Console	69
4.2.5.1 Required Browser Settings.....	69
4.2.5.2 Username and Password	69
4.2.5.3 Default User Name and Password	70
4.2.5.4 Need to change password	71
4.2.6 Menu Bar and Quick Button.....	73
4.2.6.1 Menu Bar	73
4.2.6.2 Quick Button and Logged-in User	74
4.2.7 Dashboard	75

4.2.8 Sensor	76
4.2.9 FRU Information	79
4.2.10 PSU Information	81
4.2.11 Logs & Reports	82
4.2.11.1 IPMI Event Log	83
4.2.11.2 Audit Log	85
4.2.12 Settings	86
4.2.12.1 Date & Time	87
4.2.12.2 Log Settings	91
4.2.12.2.1 SEL Log Setting Policy	91
4.2.12.3 Network Settings	95
4.2.12.4 Platform Event Filter	104
4.2.12.5 Services	115
4.2.12.6 SMTP Settings	118
4.2.12.7 System Firewall	122
4.2.12.7.1 General Firewall Settings	122
4.2.12.8 User Management	131
4.2.12.9 Power Restore Policy	136
4.2.12.10 Zone Configurations	137
4.2.13 Remote Control	138
4.2.13.1 Launch Serial Over LAN	138
4.2.14 Chassis Identify	139
4.2.15 HDD Management	140
4.2.16 Power Control	141
4.2.17 Maintenance Group	142
4.2.17.1 Backup Configuration	143
4.2.17.2 Backup Configuration	144
4.2.17.3 Firmware Image Location	147
4.2.17.4 BMC Firmware Information	149
4.2.17.5 Preserve Configuration	150
4.2.17.6 Restore Configuration	155
4.2.17.7 Restore Factory Defaults	156
4.2.17.8 CPLD Firmware Update	157
4.2.17.9 Reset BMC	158
4.2.18 Sign Out	159
4.2.19 Utility & Tool	160
4.2.19.1 Flash Tools	160
4.2.20 SOL (Serial Over LAN)	196
4.2.21 Enhanced Quick Search support (HTML5 UI Only)	197
4.2.22 OTP (One Time Password)	198
Chapter 5. Technical Support	200
Appendix	201



Copyright © 2024 AIC®, Inc. All Rights Reserved.

This document contains proprietary information about AIC® products and is not to be disclosed or used except in accordance with applicable agreements.

Document Release History

Release Date	Version	Update Content
May 2024	1	Release to public.
October 2024	1.1	Add 3.5" HDD removal info.

Preface

Copyright

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photo-static, recording or otherwise, without the prior written consent of the manufacturer.

Trademarks

All products and trade names used in this document are trademarks or registered trademarks of their respective holders.

Changes

The material in this document is for information purposes only and is subject to change without notice.

Warning

1. A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Disclaimer

AIC® shall not be liable for technical or editorial errors or omissions contained herein. The information provided is provided "as is" without warranty of any kind. To the extent permitted by law, neither AIC® or its affiliates, subcontractors or suppliers will be liable for incidental, special or consequential damages including downtime cost; lost profits; damages relating to the procurement of substitute products or services; or damages for loss of data, or software restoration. The information in this document is subject to change without notice.

Instruction Symbols

Special attention should be given to the instruction symbols below.



NOTE

This symbol indicates that there is an explanatory or supplementary instruction.



CAUTION

This symbol denotes possible hardware impairment. Upmost precaution must be taken to prevent serious hardware damage.



WARNING

This symbol serves as a warning alert for potential body injury. The user may suffer possible injury from disregard or lack of attention.

Safety Instructions

Before getting started, please read the following important cautions:

- All cautions and warnings on the equipment or in the manuals should be noted.
- Most electronic components are sensitive to electrical static discharge. Therefore, be sure to ground yourself at all times when installing the internal components.
- Use a grounding wrist strap and place all electronic components in static-shielded devices. Grounding wrist straps can be purchased in any electronic supply store.
- Be sure to turn off the power and then disconnect the power cords from your system before performing any installation or servicing. A sudden surge of power could damage sensitive electronic components.
- Do not open the system's top cover. If opening the cover for maintenance is a must, only a trained technician should do so. Integrated circuits on computer boards are sensitive to static electricity. Before handling a board or integrated circuit, touch an unpainted portion of the system unit chassis for a few seconds. This will help to discharge any static electricity on your body.
- Place this equipment on a stable surface when install. A drop or fall could cause injury.
- Please keep this equipment away from humidity.
- Carefully mount the equipment into the rack, in such manner, that it won't be hazardous due to uneven mechanical loading.
- This equipment is to be installed for operation in an environment with maximum ambient temperature below 35°C.
- The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- Never pour any liquid into ventilation openings. This could cause fire or electrical shock.
- Make sure the voltage of the power source is within the specification on the label when connecting the equipment to the power outlet. The current load and output power of loads shall be within the specification.
- This equipment must be connected to reliable grounding before using. Pay special attention to power supplied other than direct connections, e.g. using of power strips.
- Place the power cord out of the way of foot traffic. Do not place anything over the power cord. The power cord must be rated for the product, voltage and current marked on the product's electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product.
- If the equipment is not used for a long time, disconnect the equipment from mains to avoid being damaged by transient over-voltage.
- Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.

- If one of the following situations arise, the equipment should be checked by service personnel:
 1. The power cord or plug is damaged.
 2. Liquid has penetrated the equipment.
 3. The equipment has been exposed to moisture.
 4. The equipment does not work well or will not work according to its user manual.
 5. The equipment has been dropped and/or damaged.
 6. The equipment has obvious signs of breakage.
 7. Please disconnect this equipment from the AC outlet before cleaning. Do not use liquid or detergent for cleaning. The use of a moisture sheet or cloth is recommended for cleaning.
- Module and drive bays must not be empty! They must have a dummy cover.

CAUTION



The equipment intended for installation should be placed in Restricted Access Location.

CAUTION



This unit may have more than one power supply. Disconnect all power sources before maintenance to avoid electric shock.



About This Manual

Thank you for selecting and purchasing J4060-04-35X.

This user's manual is provided for professional technicians to perform easy hardware setup, basic system configurations, and quick software startup. This document pellucidly presents a brief overview of the product design, device installation, and firmware settings for J4060-04-35X. For the latest version of this user's manual, please refer to the AIC® website: <https://www.aicipc.com/en/productdetail/51367>.

Chapter 1 Product Features

J4060-04-35X is an ideal SAS JBOD that is specifically designed to accommodate diverse corporations and enterprises who pursue flexibility, easy control, and density in external or backup storage. This product supports designs and is easily deployed for your benefit.

Chapter 2 Hardware Setup

This chapter displays an easy installation guide for assembling the main components of the JBOD. Utmost caution for proceeding to set up the hardware is highly advised. Do not endanger yourself by placing the device in an unstable environment. The consequences for negligent actions may be extremely severe.

Chapter 3 Expander Configuration Setup

This chapter provides details about the supported features and unsupported configurations about your host(s) and expander controller connection.

Chapter 4 BMC Configuration Settings

This chapter illustrates the diverse functions of IPMI BMC, including the details on logging into the web page and assorted definitions. These descriptions are helpful in configuring various functions through Web GUI without entering the BIOS setup.

Chapter 5 Technical Support

For more information or suggestion, please contact the nearest AIC® corporation representative in your district or visit the AIC® website: <https://www.aicipc.com/en/index>. It is our greatest honor to provide the best service for our customers.

Chapter 1. Product Features

J4060-04-35X is a high performance JBOD product that includes 60 x 3.5" drive bays and single/dual expander module(s). For more information about our product, please visit our website at <https://www.aicipc.com/en/index>.

Before removing the subsystem from the shipping carton, visually inspect the physical condition of the shipping carton. Exterior damage to the shipping carton may indicate that the contents of the carton are damaged. If any damage is found, do not remove the components; contact the dealer where the subsystem was purchased for further instructions. Before continuing, first unpack the subsystem and verify that the contents of the shipping carton are all there and in good condition.

1.1 Box Content

This product contains the components listed below.

Please confirm the number and the condition of the components before installation.

- System chassis
(includes power supply, fan & hard disk drive tray)
- Power cord (vary per region)
- Cable management kit x 1 (optional)
- Slide rail x 1 set

PACKAGE CONTENT MAY VARY PER REGION.

1.2 Specifications

General	Number of Expander	Single/Dual	Electrical and Environmental	Universal A/C Input	Platinum/Titanium 800W: • 100~127V~, 50/60Hz, 10A • 200~240V~, 50/60Hz, 5A Platinum 1200W: • 100~127V,50/60Hz,10A; Total Power 800W • 200~240V,50/60Hz,8A; Total Power 1200W Titanium 1300W: • 100-127V~,50/60Hz,12A • 200-240V~,50/60Hz, 8.5A
	Expander Chip	Broadcom SAS35X40			
	Host/Expansion Interface	4 x Mini SAS HD (SFF-8644) per expander module			
Drives Supported	Drive Interface	12Gb SAS (Single/Dual) / 6Gb SATA (Single)		Operating Environment	• Temperature : 0°C to 35°C • Relative humidity : 20% to 80%
	Form Factor	3.5"		Non-operating Environment	• Storage temperature : -20° to 60°C • System relative humidity : 10% to 90%
Administration / Management	Admin/Firmware Upgrade	• In-band & Serial port interface • IEM port	Physical Specification	Dimensions (W x D x H)	mm : 434 x 750 x 176 inches : 17.1 x 29.5 x 6.9
	LED indicators, Audible Alarm	Yes		Gross Weight (w/ PSU, w/o Rail)	kgs : 39.5 lbs : 87.1
Hot swap and Redundancy	Drive Bays	60		Packaging Dimensions (W x D x H)	mm : 640 x 1110 x 420 inches : 25.2 x 43.7 x 16.5
	Cooling	6 x 120x38mm hot swap fans		Standard	37" tool-less rail
	Power Supply	• 800W 1+1 80+ Platinum/Titanium • 1200W 1+1 80+ Platinum • 1300W 1+1 80+ Titanium	Mounting	Option	Cable Management Kit
	Power Entry	Dual AC inlet			


1.3 Feature

J4060-04-35X is a reliable SAS JBOD with 60 drives bays. This product is designed to accommodate single/dual hub expanders with 4 Mini SAS HD wide ports. Featuring the expander chip, Broadcom SAS35x40, which is underscored for its high scalability and performance of supporting up to 12 Gb/s, this product enhances these features by integrating designs, redundant fans, and expansion to offer easy control and high performance for our customers.

- 4U high-density JBOD supports 60 hot-swap 3.5" SAS/SATA drive bays
- IPMI compliance BMC Intelligent Enclosure Management
- Hot swap design for maintenance and management
- Enclosure Cable Management Kit
- Optimized for 1000mm Depth Rack-mount Server Cabinet


Front Panel

J4060-04-35X offers 1 system buttons (System Power switch) and 4 LED indicators (Power, Power Fail, Temperature (overheating), and Fan Fault).



Item	Description		
	Power Button	Normal	Off
		Press	Boot off
		Long Press	System shutdown
	Power Status LED	On	Blue
		Off	No status
	Power Failure LED	Normal	Off
		Failed	Red
	Temperature (Overheating) LED	Normal	Off
		Failed	Red
	Fan Fault LED	Normal	Off
		Failed	Red


Rear Panel




Item	Description
1	• 800W 1+1 80+ Platinum/Titanium • 1200W 1+1 80+ Platinum • 1300W 1+1 80+ Titanium
2	6 x 120x38mm hot swap fans
3	2 x BMC console port (1 per expander)
4	2 x BMC LAN port (1 per expander)
5	8 x SFF-8644 wide port (4 per expander)
6	2 x Expander console port (1 per expander)

Rear Expander Panel

J4060-04-35X offers single/dual expander(s) with 1 BMC port and 4 mini SAS HD ports per expander module.



Top View




Item	Description
1	• 800W 1+1 80+ Platinum/Titanium • 1200W 1+1 80+ Platinum • 1300W 1+1 80+ Titanium
2	6 x 120x38mm hot swap fans
3	60 x hot swap drive bays
4	RTC board

Chapter 2. Hardware Setup

2.1 Top Cover

- ① Press the release button on both sides of the top cover and simultaneously push the cover towards the front panel.
- ② Lift upward to remove the cover from the chassis.




This information is provided for professional technicians only.


2.2 Disk Drive

2.2.1 Installing the 3.5" Hard Disk Drive


- ① Match the dimples on the HDD with the tool-less tray.
- ② Align the HDD with the tray by placing it against each other.



- ③ Insert the HDD into the tool-less tray in the suggested order above. Make certain to attach the side of the tray with the larger dimples to the HDD first and the side with the smaller dimples last for easier installation.




- ④ Complete the installation.



2.2.2 Removing the 3.5" HDD from the Tray

Pull the sides of the tray to remove the HDD. Make certain to pull the tray with smaller dimples first away from the HDD and the larger dimples last for easier removal.



NOTE

When you remove the HDD from the tray, please push out the disk only from one direction to avoid causing damage. According to the image display above, the dimples should be on the bottom of the tray.


2.2.3 Removing and Installing the HDD Tray

2.2.3.1 Installing the HDD Tray

- ① Insert the drive tray into chassis HDD cage. Make sure the drive tray is correctly secured in place when its front edge aligns with the bay edge.
- ② Push the tray lever until it reaches the end and clicks.

2.2.3.2 Removing the HDD Tray

- ① Press the release button on the tray lever.
- ② Pull upwards to remove the HDD tray from the enclosure.



This information is provided for professional technicians only.


2.3 Power Supply Unit Module

2.3.1 Installing the Power Supply Unit

Push the power supply module into the enclosure. Make sure the latch on the module is fully hooked onto the PSU housing.

2.3.2 Removing the Power Supply Unit

- ① Remove power cables connected to the power supply module.
Allow a minute for fan to spin down.
- ② Push the latch and hold the tray handle.
- ③ Pull the power supply module gently until it slides out of the enclosure.



This information is provided for professional technicians only.


2.4 Fan Module

2.4.1 Installing the Fan

Remove the top cover of the chassis (Please refer to [Section 2.1 Top Cover](#)) and insert the fan into the JBOD.

2.4.2 Removing the Fan

- ① Unplug the fan cables and connectors from the server board.
- ② Pull the top fan out of the chassis.



This information is provided for professional technicians only.


2.5 Expander Module

2.5.1 Installing the Expander

- ① Smoothly push the expander into the chassis.
- ② Fasten the captive screws to secure the expander module.

2.5.2 Removing the Expander

- ① Dislodge the captive screws that circle in red.
- ② Pull the handle and remove the module out of the chassis.



This information is provided for professional technicians only.

2.6 Slide Rail



NOTE

This section provides a basic instruction for mounting the slide rail onto the system. Tool-less rails vary per order. The rail in this manual may not exactly match the rail for your system. Please refer to the specifications or quick installation guide that came with your purchased product.




CAUTION

The rack may tilt and fall due to incorrect installation or placed on uneven grounds. The rack must be placed in a flat surface before you begin to slide the system barebone in for servicing.

Length	Elongation length	Available cabinet rack (without CMA)
932.8 mm	611.8 mm	1000mm


1. Pull the inner rail out of the slide rail until it clicks.
2. Detach the inner rail completely from the slide rail by pulling the white tab forward.




3. After the inner rail is dislodged, adjust the middle rail back to its original position by pushing the tab on the middle rail.



4. Install the inner rail onto the system barebone. Lock the keyholes and secure the screws on sides of the system.




5. Continue installing the outer rail bracket to the mounting frame. Attach the outer rail assembling to the frame and press the bracket to form a rack on both ends. Repeat to fully mount the bracket assembly on the other side.



Attach and press bracket.


bracket secured.

6. Pull out the middle channel until the ball bearing retainer is locked forward.

**NOTE**

Verify ball bearing retainer is locked forward.


7. Slide the release tab and push barebone into rack. Make sure the barebone is completely installed onto the rack.




This information is provided for professional technicians only.

2.7 Standard Cabling


2.7.1 Single expander JBOD and 1 host server with 1 HBA card



2.7.2 Dual expander JBOD and 1 host server with 2 HBA cards



2.7.3 Dual expander JBOD and 2 host servers with 1 HBA card each



2.8 Hardware Settings

2.8.1 Drive Backplane: 30 Bay

2.8.1.1 SAS PHY mapping


HDD1	HDD2	HDD3	HDD4	HDD5	HDD6	HDD7	HDD8	HDD9	HDD10	HDD11	HDD12	HDD13	HDD14	HDD15
PHY11	PHY10	PHY09	PHY08	PHY07	PHY06	PHY05	PHY04	PHY03	PHY02	PHY01	PHY00	PHY31	PHY30	PHY29




HDD16	HDD17	HDD18	HDD19	HDD20	HDD21	HDD22	HDD23	HDD24	HDD25	HDD26	HDD27	HDD28	HDD29	HDD30
PHY12	PHY13	PHY14	PHY15	PHY24	PHY25	PHY26	PHY27	PHY32	PHY33	PHY34	PHY35	PHY36	PHY37	PHY38

2.8.1.2 Placement

Top view



Bottom view



2.8.1.3 Connector


External connectors

Connector Function	Physical Description	Comments
HDD1~30	SFF-8680 SAS Receptacle(SMT H:14.15mm)	HDD connector

Internal Connectors

Connector Function	Physical Description	Comments
Power Supply (JPW1)	15 x 2 Pin Power Connector	12V. 4.5 A per pin.
Power Supply (JPW2)	4 x 2 Pin Power Connector	12V. 4.5 A per pin.
SAS SLIMLINE (SASHD_P~SASHD_S)	SFF-8654 8I	SAS Host connection
UART (JEXP_UART, JEXP_UART1)	3 x 2 Pin Header	Expander SMART/DEBUG port.
LED Board (LED-BD1)	6 x 2 Pin Header	Connect to Front LED Board
FAN Connect	1 x 4 Pin Header	For debug FAN Connect

Location




Power Connector (JPW1)




Pin	Description	Pin	Description
13	GND	1	GND
14	GND	2	GND
15	GND	3	GND
16	GND	4	GND
17	GND	5	GND
18	GND	6	GND
19	+12V	7	+12V
20	+12V	8	+12V
21	+12V	9	+12V
22	+12V	10	+12V
23	+12V	11	+12V
24	+12V	12	+12V

Power Connector (JPW2)




Pin	Description	Pin	Description
5	GND	1	GND
6	GND	2	GND
7	+12V	3	+12V
8	+12V	4	+12V

Control for Expander (JEXP_UART, JEXP_UART1)




Pin	Description	Pin	Description
2	DBG_SIRXD	1	SM_SIRXD
4	GND	3	GND
6	DBG_SITXD	5	SM_SITXD

Front LED Board Control for Display HDD LED Status (LED-BD1)



Pin	Description	Pin	Description
1	+3V3	2	+5V
3	SLOAD2	4	SDATAOUT2
5	SCLOCK2	6	GND
7	SLOAD1	8	SDATAOUT1
9	SCLOCK1	10	CPLD SDA
11	CPLD SCL	12	GND

Fan connect for debug used JFAN1,FAN2




Pin	Description
1	GND
2	+12V
3	FAN_TACH
4	FAN_PWM

2.8.1.4 LED Indicator

Indicator	Color	Behavior	Description
SAS PHY Link Status (LEDA1 to LEDA16)	Blue	On	Link up
		Blinking	Activity detected
		Off	Link down
Expander Blink (LED31,LED32)	Blue	Blinking	Expander alive, 0.0833Hz (12 seconds per cycle)
Expander Heart Bit (LED33,LED34)	Blue	Blinking	Expander FW running
HDD Activity LEDs	Blue	On	HDD present
		Blinking	HDD Activity detected : 8Hz HDD Locate : 0.5Hz
		Off	HDD no connect or Power Off
HDD Fault/Status LEDs	Red	On	Set by any of the following bits: 1. RQST MISSING 2. RQST FAULT
		Blinking	Set by any of the following bits: 1. RQST CONS CHECK 2. RQST IN CRIT ARRAY 3. RQST IN FAILED ARRAY 4. RQST REBUILD/REMAP 5. RQST R/R ABORT 6. RQST INSERT 7. RQST REMOVE 8. PRDFAIL
		Off	No control bit is set or set by any of the following bits: 1. RQST OK 2. RQST RSVD DEVICE 3. RQST HOT SPARE 4. RQST ACTIVE 5. DO NOT REMOVE 6. RQST IDENT 7. DEVICE OFF


LED Location




2.8.2 Expander Backplane

2.8.2.1 Placement

Top view



Bottom view



2.8.2.2 Connector


External connectors

Connector Function	Physical Description	Comments
MiniSAS-HD (CN1,CN2)	72 pin MiniSAS-HD 8x	SAS Host/Up/Down connection
BMC UART(J1)	Phone Jack(3.5mm)	Debug/Smart port
10/100/1000 LAN(J5)	RJ45 connector	SOL Link


Internal Connectors

Connector Function	Physical Description	Comments
UART (JEXP_UART)	3 x 2 Pin Header	Expander SMART/DEBUG port.

Location




BMC UART (J1)




Pin	Description
1	GND
2	RX
3	TX

10/100/1000 LAN (J5)



Pin	Description
1	MDI0_PHY_P
2	MDI0_PHY_N
3	MDI1_PHY_P
4	MDI1_PHY_N
5	GND
6	GND
7	MDI2_PHY_P
8	MDI2_PHY_N
9	MDI3_PHY_P
10	MDI3_PHY_N

Console for Expander (JEXP_UART)





Pin	Description	Pin	Description
2	DBG_SIRXD	1	SM_SIRXD
4	GND	3	GND
6	DBG_SITXD	5	SM_SITXD

2.8.2.3 LED Indicator

Indicator	Color	Behavior	Description
UP/DOWN Link Status LEDs (LED3, LED5, LED7, LED9)	Blue	On	Link up
		Off	NO Link down
UP/DOWN Link Status LEDs (LED4, LED6, LED8, LED10)	Red	On	Phy Loss
		Off	Phy Normal
Expander Blink (LED1)	Blue	Blinking	Expander alive, 0.0833Hz (12 seconds per cycle)
Expander Heart Bit (LED2)	Blue	Blinking	Expander FW running
BMC ID LED (LED2000)	Blue	On	ID LED indicator
BMC Heart beat LED/ Status LED (LED2001)	Blue	On	10Hz : ARM Running on Flash. (instruction fetch from flash). 2Hz : ARM Running on DRAM without interrupt enabled. (instruction fetch from DRAM) 0.5Hz : ARM Running on DRAM with interrupt monitor enabled. The(normal operation mode). 0.1Hz : Abonormal mode, some interrupts are not serviced for over 2 seconds. 0Hz : Always dark indicates firmware is not running or dead.
	Red	On	System Fail


Location



2.8.2.4 Jumper


BMC UART Mode Option Description(JUART_TX1, JUART_RX1):

JUART_TX1



Pin	JUART_TX1 Setting Description
Pin 1,2 short	Smart Port Enable
Pin 2,3 short	Debug Port Enable

JUART_RX1




Pin	JUART_TX1 Setting Description
Pin 1,2 short	Smart Port Enable
Pin 2,3 short	Debug Port Enable

SPI CS0 select(JBKP1) Description:

SPI CS0 select (JBKP1)	FW_SPI_CS_N	SPI CS 0 Enable	Pin 1,2 Short
	+3V3 level	SPI CS 0 Disable	Pin 1,2 open
	GPIOK4	GPIOK4 High CS0 to Main ROM, CS1 to Backup ROM	
		GPIOK4 Low CS1 to Main ROM, CS0 leave	


Location




2.8.3 Connect Board Backplane

2.8.3.1 Placement

Top view



Bottom view



2.8.3.2 Connector


External Connectors

Connector Function	Physical Description	Comments
PSU1-2(PWR1,2)	CRPS	12V PWR, 12V_STBY PWR
EXPANDER BOARD(J5,J6)	GenZ_280P	GenZ_8C_STRADDLE (PCIE GEN5)

Internal Connectors

Connector Function	Physical Description	Comments
SASHD_P1-2	SLIMLINE 74P	SLIMLINE_VERTICAL_SMD(PCie GEN5)
SASHD_S1-2	SLIMLINE 74P	SLIMLINE_VERTICAL_SMD(PCie GEN5)
PWR3,5	ATX_12X2P	12V PWR
PWR6,7	ATX_4X2P	12V PWR
FRONT PANEL(J1)	Header_2X5P	LED
FAN1-6(JFAN1-6))	Header_1X4P	FAN


Fan Location



Chapter 3 Expander Configuration Settings

3.1 Supported Configuration and Unsupported Feature

3.1.1 Support Multiple Host/Path Access



To have multiple host/path access support (the host number can be up to the number of wide ports on each AIC® 12G Expander Controller), only the following drives are supported for shared access:

1. SAS drive / Nearline SAS drive
2. SATA drive with an interposer which provides SATA-to-SAS conversion

3.1.2 Unsupported Feature

1. Enclosure logical identifier can be changed.
2. Locate a drive via any HBA utility. Users should send standard SES command to the enclosure (4U60-Hub / 4U90-Hub) to locate a drive.

3.2 SES Inband Features

To ensure proper function, high performance, and durability, J4060-04-35X has implemented SCSI Enclosure Services to monitor the status of power supply, system cooling fan, and working temperature. It also has indicators to deliver the status of fail devices such as power supply or cooling fan. You can get the information directly from the front indicators to know how your enclosure works.

For detailed information, please visit <http://www.t10.org>

If you are a member of the T10 working group, the Standard which controlled by T10 technical committee, could be found at

<http://www.t10.org/cgi-bin/ac.pl?t=f&f=ses2r19a.pdf>

3.2.1 SES Pages

- 00h - List of supported diagnostic pages
- 01h - SES configuration
- 02h - SES enclosure control / enclosure status
- 05h - SES Threshold Out / In
- 07h - SES element descriptor
- 0Ah - SES additional element
- 0Eh - SES download microcode control / SES download microcode status
- 82h - SES vendor specific page: Chassis Number
- 83h - SES vendor specific page: Canister Number
- 8Ch - SES Vendor specific page : Firmware Version and MFG Version
- 8Dh - SES vendor specific page: BMC Firmware Version

3.2.2 SES Elements

- 02h - Power Supply
- 03h - Cooling
- 04h - Temperature Sensor
- 0Eh - Enclosure
- 12h - Voltage
- 17h - Array Device

3.2.3 Implementation on SES Pages

SES Threshold Out / In

It includes only Temperature Sensor and Voltage Sensor elements.

Threshold control element format

BYTE/BIT	7	6	5	4	3	2	1	0
0	REQUESTED HIGH CRITICAL THRESHOLD							
1	REQUESTED HIGH WARNING THRESHOLD							
2	REQUESTED LOW WARNING THRESHOLD							
3	REQUESTED LOW CRITICAL THRESHOLD							

Threshold status element format

BYTE/BIT	7	6	5	4	3	2	1	0
0	HIGH CRITICAL THRESHOLD							
1	HIGH WARNING THRESHOLD							
2	LOW WARNING THRESHOLD							
3	LOW CRITICAL THRESHOLD							

SES Vendor specific page: Chassis Number (page code 82h) Out / In

The length N of chassis number can be 0~247 bytes. If no canister number is entered (N=0), then chassis number is cleared.

Chassis Number control format

BYTE/BIT	7	6	5	4	3	2	1	0
0~N	Chassis Number							

If no chassis number is found, return Status = 1 (failed). Otherwise report Status = 0 (success) followed by chassis number.

Chassis Number status format

BYTE/BIT	7	6	5	4	3	2	1	0
0	Status (0: success, 1: failed)							
1~N (if success)	Chassis Number							

SES vendor specific page: Canister Number (page code 83h) Out / In

The length N of canister number can be 0 ~ 247 bytes. If no canister number is input (N=0), then canister number is restored to its SAS address.

Canister Number control format

BYTE/BIT	7	6	5	4	3	2	1	0
0~N	Canister Number							

If no canister number is found, report Status = 1 (failed). Otherwise report Status = 0 (success) followed by canister number.

Canister Number status format

BYTE/BIT	7	6	5	4	3	2	1	0
0	Status (0: success, 1: failed)							
1~N (if success)	Canister Number							

SES Vendor specific page: Firmware Version and MFG Version (page code 8Ch) In

There are one firmware version (4 bytes) and one MFG version (4 bytes) per expander.
There are 3 expanders in 4U60 and 4 expanders in 4U90.

Firmware Version and MFG Version status format

BYTE/BIT	7	6	5	4	3	2	1	0
0~3	Hub expander firmware version							
4~7	Hub expander MFG version							
8~11	First Edge firmware version							
12~15	First Edge MFG version							
16~19	Second Edge firmware version							
20~23	Second Edge MFG version							
24~27	Third Edge firmware version (only applicable to 4U90)							
28~31	Third Edge MFG version (only applicable to 4U90)							

SES vendor specific page: BMC Firmware Version (page code 8Dh) In

There are 3 bytes for BMC firmware version.

BMC Firmware Version status format

BYTE/BIT	7	6	5	4	3	2	1	0
0-2	BMC Firmware Version							

3.2.4 Implementation on SES Elements

Only the fields highlighted in green are supported.

Power Supply Element

(A) Power Supply Control Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	Reserved						
2	Reserved							
3	Reserved	RQST FAIL	RQST ON	Reserved				

(B) Power Supply Status Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	IDENT	Reserved						
2	Reserved				DC OVER VOLTAGE	DC UNDER VOLTAGE	DC OVER CURRENT	Reserved
3	HOT SWAP	FAIL	RQSTED ON	OFF	OVERTMP FAIL	TEMP WARN	AC FAIL	DC FAIL

Field	Value
ELEMENT STATUS CODE	OK: No failure or warning conditions detected CRITICAL: FAIL bit is set due to one or more failure condition UNKNOWN: The power supply can't be read
DC OVER CURRENT	An output overcurrent fault has occurred
FAIL	A failure condition is detected
OVERTMP FAIL	Over temperature fault has occurred
TEMP WARN	Over temperature warning has occurred
AC FAIL	A failure condition is detected
DC FAIL	A failure condition is detected

Cooling Element

(A) Cooling Control Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	Reserved						
2	Reserved							
3	Reserved	RQST FAIL	RQST ON	Reserved		REQUESTED SPEED CODE		

Field	Value
RQST IDENT	Please refer to section “SES Element Control Functions” for details.
REQUESTED SPEED CODE	Please refer to section “SES Element Control Functions” for details.

(B) Cooling Status Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	IDENT	Reserved				ACTUAL FAN SPEED (MSB)		
2	ACTUAL FAN SPEED (LSB)							
3	HOT SWAP	FAIL	RQSTED ON	OFF	Reserved	ACTUAL SPEED CODE		

Field	Value
ELEMENT STATUS CODE	OK: Everything is Ok NON-CRITICAL: Either warning limit is exceeded CRITICAL: The fan RPM can't be detected, or either failure limit is exceeded. UNKNOWN: The fan RPM can't be read
IDENT	Applicable only for Cooling element 0 0: Enable the auto fan function 1: Disable the auto fan function
ACTUAL FAN SPEED	Current fan RPM
FAIL	The fan RPM can't be detected, or either failure limit is exceeded.

Temperature Sensor Element

(A) Temperature Sensor Control Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	RQST FAIL	Reserved					
2	Reserved							
3	Reserved							

(B) Temperature Sensor Status Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	IDENT	FAIL	Reserved					
2	TEMPERATURE							
3	Reserved				OT FAILURE	OT WARNING	UT FAILURE	UT WARNING

Field	Value
ELEMENT STATUS CODE	OK: Everything is Ok NON-CRITICAL: Either warning limit is exceeded CRITICAL: Either failure limit is exceeded UNKNOWN: The temperature can't be read
FAIL	A warning or failure condition is detected
TEMPERATURE	Temperature reading
OT FAILURE	Temperature has exceeded the failure high threshold value
OT WARNING	Temperature has exceeded the warning high threshold value
UT FAILURE	Temperature is below the failure low threshold value
UT WARNING	Temperature is below the warning low threshold value

Enclosure Element**(A) Enclosure Control Element**

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	Reserved						
2	POWER CYCLE REQUEST		POWER CYCLE DELAY					
3	POWER OFF DURATION						REQUEST FAILURE	REQUEST WARNING

Field	Value
REQUEST FAILURE	Please refer to section “SES Element Control Functions” for details.
REQUEST WARNING	Please refer to section “SES Element Control Functions” for details.

(B) Enclosure Status Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	IDENT	Reserved						
2	TIME UNTIL POWER CYCLE						FAILURE INDICATION	WARNING INDICATION
3	REQUEST POWER OFF DURATION						FAILURE REQUESTED	WARNING REQUESTED

Field	Value
ELEMENT STATUS CODE	OK
FAILURE REQUESTED	Set by the REQUEST FAILURE on Enclosure Control Element
WARNING REQUESTED	Set by the REQUEST WARNING on Enclosure Control Element

Voltage Element

(A) Voltage Control Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	RQST FAIL	Reserved					
2	Reserved							
3	Reserved							

(B) Voltage Status Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	IDENT	FAIL	Reserved		WARN OVER	WARN UNDER	CRIT OVER	CRIT UNDER
2	VOLTAGE							
3								

Field	Value
ELEMENT STATUS CODE	OK: Everything is Ok NON-CRITICAL: Either warning limit is exceeded CRITICAL: Either failure limit is exceeded UNKNOWN: The voltage can't be read
FAIL	A warning or failure condition is detected
WARN OVER	Voltage has exceeded the warning high threshold value
WARN UNDER	Voltage is below the warning low threshold value
CRIT OVER	Voltage exceeds the failure high threshold value
CRIT UNDER	Voltage is below the failure low threshold value
VOLTAGE	Voltage reading

Array Device Element

(A) Array Device Control Element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved0			
1	RQST OK	RQST RSVD DEVICE	RQST HOT SPARE	RQST CONS CHECK	RQST IN CRIT ARRAY	RQST IN FAILED ARRAY	RQST REBUILD/REMAP	RQST R/R ABORT
2	RQST ACTIVE	DO NOT REMOVE	Reserved 2	RQST MISSING	RQST INSERT	RQST REMOVE	RQST IDENT	Reserved 1
3	Reserved 5	Reserved 4	RQST FAULT	DEVICE OFF	ENABLE BYP A	ENABLE BYP B	Reserved3	

Field	Value
PRDFAIL	Please refer to section “SES Element Control Functions” for details.
RQST OK	Please refer to section “SES Element Control Functions” for details.
RQST RSVD DEVICE	Please refer to section “SES Element Control Functions” for details.
RQST HOT SPARE	Please refer to section “SES Element Control Functions” for details.
RQST CONS CHECK	Please refer to section “SES Element Control Functions” for details.
RQST IN CRIT ARRAY	Please refer to section “SES Element Control Functions” for details.
RQST IN FAILED ARRAY	Please refer to section “SES Element Control Functions” for details.
RQST REBUILD/REMAP	Please refer to section “SES Element Control Functions” for details.
RQST R/R ABORT	Please refer to section “SES Element Control Functions” for details.
RQST ACTIVE	Please refer to section “SES Element Control Functions” for details.
DO NOT REMOVE	Please refer to section “SES Element Control Functions” for details.
Reserved2	Please refer to section “SES Element Control Functions” for details.
RQST MISSING	Please refer to section “SES Element Control Functions” for details.
RQST INSERT	Please refer to section “SES Element Control Functions” for details.
RQST REMOVE	Please refer to section “SES Element Control Functions” for details.
RQST IDENT	Please refer to section “SES Element Control Functions” for details.
Reserved5	Please refer to section “SES Element Control Functions” for details.
RQST FAULT	Please refer to section “SES Element Control Functions” for details.
DEVICE OFF	Please refer to section “SES Element Control Functions” for details.

(B) Array Device Status Element

BYTE/ BIT	7	6	5	4	3	2	1	0
0	COMMON STATUS							
	Reserved	PRDFAIL	DISABLE	SWAP	ELEMENT STATUS CODE			
1	OK	RSVD DEVICE	HOT SPARE	CONS CHK	IN CRIT ARRAY	IN FAILED ARRAY	REBUILD/ REMAP	R/R ABORT
2	APP CLIENT BYPASSED A	DO NOT REMOVE	ENCLOSURE BYPASSED A	ENCLOSURE BYPASSED B	READY TO INSERT	RMV	IDENT	REPORT
3	APP CLIENT BYPASSED B	FAULT SENSED	FAULT REQSTD	DEVICE OFF	BYPASSED A	BYPASSED B	DEVICE BYPASSED A	DEVICE BYPASSED B

Field	Value
PRDFAIL	Set by the PRDFAIL on Array Device Control Element
ELEMENT STATUS CODE	OK: A drive is detected in the slot NOT INSTALLED: No drive is installed in the slot
OK	Set by the RQST OK on Array Device Control Element
RSVD DEVICE	Set by the RQST RSVD DEVICE on Array Device Control Element
HOT SPARE	Set by the RQST HOT SPARE on Array Device Control Element
CONS CHK	Set by the RQST CONS CHECK on Array Device Control Element
IN CRIT ARRAY	Set by the RQST IN CRIT ARRAY on Array Device Control Element
IN FAILED ARRAY	Set by the RQST IN FAILED ARRAY on Array Device Control Element
REBUILD/ REMAP	Set by the RQST REBUILD/REMAP on Array Device Control Element
R/R ABORT	Set by the RQST R/R ABORT on Array Device Control Element
DO NOT REMOVE	Set by the DO NOT REMOVE on Array Device Control Element
READY TO INSERT	Set by the RQST INSERT on Array Device Control Element
RMV	Set by the RQST REMOVE on Array Device Control Element
IDENT	Set by the RQST IDENT on Array Device Control Element
FAULT REQSTD	Set by the RQST FAULT on Array Device Control Element
DEVICE OFF	Set by the DEVICE OFF on Array Device Control Element

3.2.5 SES Element Control Functions

LED indicators (blue and red) associated with an attached disk drive

Array Device Slot control element

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved0			
1	RQST OK	RQST RSVD DEVICE	RQST HOT SPARE	RQST CONS CHECK	RQST IN CRIT ARRAY	RQST IN FAILED ARRAY	RQST REBUILD/REMAP	RQST R/R ABORT
2	RQST ACTIVE	DO NOT REMOVE	Reserved 2	RQST MISSING	RQST INSERT	RQST REMOVE	RQST IDENT	Reserved 1
3	Reserved 5	Reserved 4	RQST FAULT	DEVICE OFF	ENABLE BYP A	ENABLE BYP B	Reserved 3	

The default behavior for blue LED is "LED is on when the disk is not busy, and off when the disk is executing a command." When the "RQST IDENT" bit is set, the blue LED overwrites its default behavior with a slow blink while the red LED is off. The blue LED is set "Activity" for not overwriting its default behavior.

The behavior "Fast Blink" is "LED is blinking at 2Hz frequency."

The behavior "Slow Blink" is "LED is blinking at 0.5Hz frequency."

The behavior "ON"/"OFF" is "LED is solid ON/OFF without blinking."

Slot Control Bit	Blue LED	Red LED
RQST OK	Activity	OFF
RQST RSVD DEVICE	Activity	OFF
RQST HOT SPARE	Activity	OFF
RQST CONS CHECK	Activity	Fast Blink
RQST IN CRIT ARRAY	Activity	Slow Blink
RQST IN FAILED ARRAY	Activity	Slow Blink
RQST REBUILD/REMAP	Activity	Fast Blink
RQST R/R ABORT	Activity	Slow Blink
RQST ACTIVE	Activity	OFF
DO NOT REMOVE	Activity	OFF
RQST MISSING	ON	ON
RQST INSERT	Activity	Slow Blink
RQST REMOVE	Activity	Slow Blink
RQST IDENT	Slow Blink	OFF
RQST FAULT	ON	ON
DEVICE OFF	OFF	OFF
PRDFAIL	Activity	Slow Blink

How to turn on/off the power of a drive slot**Array Device Slot control element**

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved0			
1	RQST OK	RQST RSVD DEVICE	RQST HOT SPARE	RQST CONS CHECK	RQST IN CRIT ARRAY	RQST IN FAILED ARRAY	RQST REBUILD/REMAP	RQST R/R ABORT
2	RQST ACTIVE	DO NOT REMOVE	Reserved 2	RQST MISSING	RQST INSERT	RQST REMOVE	RQST IDENT	Reserved 1
3	Reserved 5	Reserved 4	RQST FAULT	DEVICE OFF	ENABLE BYP A	ENABLE BYP B	Reserved3	

The "DEVICE OFF" for a drive slot is defined in the bit4, byte3 of the "Array Device Slot control element" in the SES specification. Set the bit to turn off a slot power, and vice versa. We use the software package "sg3_utils" on Linux for example, and have a SAS HBA and a cable to connect your host with the expander.

(A) Show the device for AIC® Expander Controller (canister)

```
$ sg_map -i
/dev/sg2  AIC 12G   4U60-Hub-P0   0c3e
```

(B) Get the current state of a slot power. The "Device off=0" means the slot power is on.

```
$ sg_ses --page=2 /dev/sg2
```

Element 0 descriptor:

App client bypass B=0, Fault sensed=0, Fault reqstd=0, Device off=0

(C) Get the descriptor of a slot power

```
$ sg_ses --page=7 /dev/sg2
```

Element 0 descriptor: Disk001

(D) Turn off a slot power

```
$ sg_ses --descriptor=Disk001 --set=3:4:1 /dev/sg2
```

(E) Turn on a slot power

```
$ sg_ses --descriptor=Disk001 --clear=3:4:1 /dev/sg2
```

How to enable/disable the enclosure alarm by your software

Enclosure control element								
BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST	Reserved						
2	POWER CYCLE REQUEST		POWER CYCLE DELAY					
3	POWER OFF DURATION						REQUEST FAILURE	REQUEST WARNING

The system alarm LED is used for the enclosure alarm and power alarm. The "REQUEST FAILURE" and "REQUEST WARNING" for Enclosure are defined in the bit1, byte3 and bit0, byte3 of the "Enclosure control element" in the SES specification. Setting either bit can enable the enclosure alarm. Clearing both bits disables the enclosure alarm. We use the software package "sg3_utils" on Linux for example, and have a SAS HBA and a cable to connect your host with the expander.

(A) Show the device for AIC® Expander Controller (canister)

```
$ sg_map -i
/dev/sg2  AIC 12G   4U60-Hub-P0   0c3e
```

(B) Enable the enclosure alarm

```
$ sg_ses --descriptor=EnclosureElement00 --set=3:1:1 /dev/sg2
or
$ sg_ses --descriptor=EnclosureElement00 --set=3:0:1 /dev/sg2
```

(C) Disable the enclosure alarm

```
$ sg_ses --descriptor=EnclosureElement00 --clear=3:1:1 /dev/sg2
and
$ sg_ses --descriptor=EnclosureElement00 --clear=3:0:1 /dev/sg2
```

How to manually change PWM (fan speed) for all Cooling elements

Cooling control element								
BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved			
1	RQST IDENT	Reserved						
2	Reserved							
3	Reserved	RQST FAIL	RQST ON	Reserved		REQUESTED SPEED CODE		

The "RQST IDENT" for Cooling is defined in the bit7, byte1 and the "REQUESTED SPEED CODE" is defined in the bit2 ~ 0, byte3 of the "Cooling control element" in the SES specification. Set "RQST IDENT" bit to disable the auto fan function, and then change PWM or fan speed for all Cooling elements by setting the "REQUESTED SPEED CODE" bits. Clear "RQST IDENT" bit to enable the auto fan function again. Please disable the auto fan function before changing PWM or fan speed. Only Cooling element 0 supports this feature. We use the software package "sg3_utils" on Linux for example, and have a SAS HBA and a cable to connect your host with the expander.

(A) Show the device for AIC® Expander Controller (canister)

```
$ sg_map -i
/dev/sg2  AIC 12G   4U60-Hub-P0   0c3e
```

(B) Set "RQST IDENT" of Cooling element 0 to disable the auto fan function

```
$ sg_ses --descriptor=CoolingElement00 --set=1:7:1 /dev/sg2
```

(C) Set "REQUESTED SPEED CODE" of Cooling element 0 to change PWM or fan speed for all Cooling elements. Set "REQUESTED SPEED CODE"=7 (100% PWM) for example.

```
$ sg_ses --descriptor=CoolingElement00 --set 3:2:3=7 /dev/sg2
```

REQUESTED SPEED CODE	PWM
7	100%
6	90%
5	80%
4	70%
3	60%
2	50%
1	40%
0	Leave at current speed

How to update firmware/MFG for Edge expanders**Array Device Slot control element**

BYTE/BIT	7	6	5	4	3	2	1	0
0	COMMON CONTROL							
	SELECT	PRDFAIL	DISABLE	RST SWAP	Reserved0			
1	RQST OK	RQST RSVD DEVICE	RQST HOT SPARE	RQST CONS CHECK	RQST IN CRIT ARRAY	RQST IN FAILED ARRAY	RQST REBULD/REMAP	RQST R/R ABORT
2	RQST ACTIVE	DO NOT REMOVE	Reserve2	RQST MISSING	RQST INSERT	RQST REMOVE	RQST IDENT	Reseved1
3	Reserved 5	Reserved 4	RQST FAULT	DEVICE OFF	ENABLE BYP A	ENABLE BYP B	Reserved3	

All Edge expanders are hidden behind Hub, so please follow the steps below to update firmware/MFG on Edge0 via inband SAS. The same steps can be applied to the other Edge expanders. We use the software package "sg3_utils" and LSI utility "g3Xflash" on Linux for example, and have a SAS HBA and a cable to connect your host with the expander.

(A) Show the device for AIC® Expander Controller (canister)

```
$ sg_map -i
/dev/sg2  AIC 12G   4U60-Hub-P0    0c3e
```

(B) Set the "Reserved2" of the first Array Device element on the Edge expander to make it visible. On 4U60, please use "Disk001" for Edge0 and "Disk031" for Edge1. On 4U90, please use "Disk001" for Edge0, "Disk031" for Edge1, and "Disk061" for Edge2.

```
$ sg_ses --descriptor=Disk001 --set=2:5:1 /dev/sg2
```

(C) Get SAS address for Hub. This example uses SAS address (500605B0:000272BF) for Hub.

```
$/g3Xflash -i get avail
```

(D) Reset Hub to have an additional device for Edge0

```
$/g3Xflash -i 500605b0000272bf reset exp
```

(E) Show the devices for Hub and Edge0

```
$ sg_map -i

/dev/sg2  AIC 12G   4U60-Hub-P0    0c3e
/dev/sg3  AIC 12G   4U60-Edge0    0c3f
```

(F) Update firmware on Edge0

```
$ sg_write_buffer --id=0x0 --in=<firmware filename> --mode=0x2 --offset=0 /dev/sg3
```

(G) Update MFG on Edge0

```
$ sg_write_buffer --id=0x83 --in=<MFG filename> --mode=0x2 --offset=0 /dev/sg3
```

(H) Get SAS address for Edge0. This example uses SAS address (50015B20:9000EBBF) for Edge0.

```
$ ./g3Xflash -i get avail
```

(I) Reset Edge0 to activate its new firmware/MFG

```
$. /g3Xflash -i 50015b209000ebbf reset exp
```

(J) Get the current firmware version on Edge0 for confirmation

```
$. /g3Xflash -i 50015b209000ebbf get ver
```

(K) Set the "Reserved5" of the first Array Device element on the Edge expander to make it invisible

```
$ sg_ses --descriptor=Disk001 --set=3:7:1 /dev/sg2
```

(L) Reset Hub to refresh the change on Edge0

```
$. /g3Xflash -i 500605b0000272bf reset exp
```

3.2.6 How to update all firmware/MFG through in-band SES

How to update all firmware/MFG through in-band SES with a tar ball which includes all Edge firmware/MFG and Hub firmware/MFG

Please follow the steps below to update all firmware/MFG through in-band SES with a tar ball which includes all Edge firmware/MFG and Hub firmware/MFG. We use the software package "sg3_utils" on Linux for example, and have a SAS HBA and a cable to connect your host with the expander. The version of the software package "sg3_utils" must be v1.41 or newer.

If Broadcom 24Gb SAS/NVMe eHBA 96xx card is used, the profile ID of the card has to be changed before all firmware/MFG update. The eHBA 96xx firmware phase 8.7 (or newer) and the utility "scrutinyCLI version 8.6" (or newer) can support the profile ID change in the following.

1. Run "show -all" using ScrutinyCLI. This should show "Profile Id: 0x2" and "Supported Profile Id: 0x2, 0x0, 0x3".
 - Profile Id 0x0: IT HBA for SAS/SATA/NVMe
 - Profile Id 0x1: EVP (Entry RAID)
 - Profile Id 0x2: Feature HBA
 - Profile Id 0x3: IT HBA for SAS/SATA only
2. Change the profile ID using "ctrl -personality -profileid 0" command
3. Reboot the system to activate the new profile
4. Run "show -all" again to confirm the new profile "Profile Id: 0x0"

(A) Show the device for AIC Expander Controller (canister)

```
$ sg_map -i
/dev/sg2 AIC 12G 4U60-Hub-P0 0c3e
```

(B) Set the time-out interval with the option "-t". The update process on 4U60_SE takes about 180 seconds, and the update process on 4U90_SE takes about 240 seconds.

```
$ sg_write_buffer /dev/sg2 --id=0x04 --bpw=4k --in=4U60_SE_4U90_SE.tar--mode=0x2
--offset=0 -t 600
```



NOTE

Instructions of how to create the file of **4U60_SE_4U90_SE.tar**, please refer to the Appendix "[How to create 4U60_SE 4U90_SE firmware MFG tarball](#)".

3.3 Configure Serial Command Line Interface Functions

Expander console port

The RS232 setting - baud rate: 38400 bps, data bits: 8, parity: none, stop bits: 1, flow control: none



NOTE

If you need to configure T10 zoning, we recommend using the "one-click" function for T10 zoning of AIC JBOD BMC. Please refer to [4.2.12.10 Zone Configurations](#) for a simple setting. The following section [4.3.2 How to configure T10 zoning](#) is for T10 zoning manual settings and can be skipped.

3.3.1 How to enable/disable T10 zoning

The default T10 zoning configuration is off.

(A) Check the current zoning state

```
cmd> phyzone state
Zoning is OFF
```

(B) Enable zoning

```
cmd> phyzone on
```

(C) Disable zoning

```
cmd> phyzone off
```

3.3.2 How to configure T10 zoning

Remove the SAS cable (SFF-8644) between the HBA/RAID card and the JBOD-4U760 before configuration T10 zoning. After configuring T10 zoning, please power cycle the JBOD-4U60 and then insert the SAS cable back (SFF-8644).

After enabling T10 zoning, five predefined groups are Group1, Group8, Group9, Group10, and Group11. Each PHY should be in one of the five groups, and all PHYs in a wide port should be in the same group. Each PHY in Group1 can access any PHY in other groups, and vice versa. Each PHY in Group8 cannot access any PHY in Group9, and vice versa.

The command syntax is "phyzone phy_index group." The following example shows how to setup one drive accessed only by the first port and another drive accessed only by the second port. The PHYs for the wide ports and drives in the example are not the PHY map in the 4U60 /4U90.

The configuration for the example is

- (A) PHY8 - PHY11 for the first wide port of HUB
- (B) PHY4 - PHY7 for the second wide port of HUB
- (C) PHY20 - PHY35 for drives on EDGE

Step 1 Read the current group for PHY4 of HUB.

```
cmd> phyzone 4
Phy 4 for Zone Group 1
```

Step 2 Assign the second port (PHY4 - PHY7) for Group9.

```
cmd> phyzone 4 9  
cmd> phyzone 5 9  
cmd> phyzone 6 9  
cmd> phyzone 7 9
```

Step 3 Assign the first port (PHY8 - PHY11) of HUB for Group8.

```
cmd> phyzone 8 8  
cmd> phyzone 9 8  
cmd> phyzone 10 8  
cmd> phyzone 11 8
```

Step 4 Assign the drive on PHY20 of EDGE to be accessed only by the first port of HUB instead of the second port.

```
cmd> phyzone 20 8
```

Step 5 Assign the drive on PHY21 of EDGE to be accessed only by the second port of HUB instead of the first port.

```
cmd> phyzone 21 9
```

Step 6 Rest HUB and EDGE for taking effect with the new settings.

```
cmd> reset
```

**NOTE****Power Cycle**

For dual expander JBOD, complete the setting of EDGE and HUB. Meanwhile, PRI EXP and SEC EXP should be applied with the same configuration. After the T10 zoning configuration, you need to power cycle the JBOD to make PRI EXP and SEC EXP simultaneously operate.

3.3.3 How to get all revisions in AIC® SAS 12G Expander

- (A) Expander firmware revision
cmd> rev
- (B) Expander configuration revision
cmd> showmfg
- (C) Sensor information, model, and CPLD firmware revision (CPLD firmware revision is reported by Hub only)
cmd> sensor

3.3.4 How to configure enclosure address (HUB only)

- (A) Get the current enclosure address
cmd> enclosure_addr
Enclosure Address: 0x500605B0000272BF
- (B) Set the enclosure address with 0x500605B0000272BF. The new setting will take effect after reset.
cmd> enclosure_addr 500605B0000272BF
cmd> reset

3.3.5 How to configure standby timer for all disk drives (EDGE only)

This feature is applicable for SAS/SATA drives. Standby timer is in units of minutes. Setting standby timer with 0 minute disables this feature.

- (A) Get current standby timer
cmd> standby_timer
Standby Timer : 0 minutes
- (B) Set the standby timer with 10 minutes. The new setting will take effect after reset.
cmd> standby_timer 10
cmd> reset



NOTE

This function is not recommended to use with RAID card due to the RAID card limitation.

3.3.6 How to configure wide port checker

This feature is applicable for SAS drives instead of SATA drives. If there is no connection with any active SAS initiator by checking all wide ports, AIC® Expander Controller stops all attached SAS drives to save power consumption of SAS drives. Otherwise, AIC® Expander Controller starts all attached SAS drives to provide drive access service to any active SAS initiator. The same setting should be applied to HUB and EGDE.

- (A) Get the current state of wide port checker

```
cmd> check_wide_port  
Checking wide port is OFF
```

- (B) Enable checking wide port. The new setting will take effect after reset.

```
cmd> check_wide_port on  
cmd> reset
```

- (C) Disable checking wide port. The new setting will take effect after reset.

```
cmd> check_wide_port off  
cmd> reset
```

3.3.7 How to power off/on all disk drives automatically

This feature is applicable for SAS/SATA drives. If there is no connection with any active SAS initiator by checking all wide ports, AIC® Expander Controller powers off all attached SAS/SATA drives to save power consumption. Otherwise, AIC® Expander Controller powers on all attached SAS/SATA drives to provide drive access service to any active SAS initiator. The same setting should be applied to HUB and EDGE.

```
cmd> check_wide_port standby  
cmd> reset
```

3.3.8 How to configure EDFB (EDGE only)

The default EDFB configuration is off.

(A) Check the current configuration

```
cmd> edfb  
EDFB is OFF
```

(B) Enable the EDFB

```
cmd>edfb on
```

(C) Disable the EDFB

```
cmd> edfb off
```

3.3.9 How to configure zone count (Hub only)

Before you begin, your JBOD must be equipped with HUB/EDGE setting.

There are 3 kinds of zoning options that can be implemented by Command Line interface operation. By using the zoning option, four of the 8644 ports will have a variety of zone group settings.

Remove the SAS cable between the HBA/RAID card and the 4U60 / 4U90 before configuring . Power the 4U60 / 4U90 off after configuring zone count. Power on the 4U60 / 4U90, and then insert the SAS cable.

Three zone configurations supported are one zone, two zones, and four zones. The default configuration is one zone of which T10 zoning configuration is disabled. T10 zoning configuration of the other configurations (two zones and four zones) is enabled.

(A) Get current zone count

```
cmd> zonecount
Zone Count 1
```

(B) Set zone count = 2

```
cmd> zonecount 2
Succeeded to set zone count 2
```

(C) Predefined zones

(C-1) For 4U60

(C-1-1) When Zone Count = 1, T10 zoning is disabled.

HUB:

Zone #	1
Wideport	1, 2, 3, 4

EDGE:

Zone #	1
Slot	1~60

(C-1-2) When Zone Count = 2, T10 zoning is enabled.

HUB:

Zone #	1	2
Wideport	1, 2	3, 4

EDGE:

Zone #	1	2
Slot	1~30	31~60

(C-1-3) When Zone Count = 4, T10 zoning is enabled.

HUB:

Zone #	1	2	3	4
Wideport	1	2	3	4

EDGE:

Zone #	1	2	3	4
Slot	1~15	16~30	31~45	46~60

(C-2) For 4U90

(C-2-1) When Zone Count = 1, T10 zoning is disabled.

HUB:

Zone #	1
Wideport	1, 2, 3, 4

EDGE:

Zone #	1
Slot	1~90

(C-2-2) When Zone Count = 2, T10 zoning is enabled.

HUB:

Zone #	1	2
Wideport	1, 2	3, 4

EDGE:

Zone #	1	2
Slot	1~45	46~90

(C-2-3) When Zone Count = 4, T10 zoning is enabled.

HUB:

Zone #	1	2	3	4
Wideport	1	2	3	4


EDGE:

Zone #	1	2	3	4
Slot	1~23	24~46	47~68	69~90


Zone Count

Zone count 1:
60 drives per zone. All SFF-8644
ports and drives are at the same zone
group.
SEE FIGURE BELOW.

Expander rear panel



Group 1





Front

Zone count 2:

30 drives per zone. Port 1 & 2 is in zone group 1. Port 3 & 4 is in zone group 2.
SEE FIGURE BELOW.

Expander rear panel





Zone count 4:

15 drives per zone. Port 1 is in zone group 1. Port 2 is in zone group 2. Port 3 is in zone group 3. Port 4 is in zone group 4.

SEE FIGURE BELOW.

Expander rear panel



3.3.10 How to configure zoning of the wide port (HUB only)

Remove the SAS cable (SFF-8644) between the HBA/RAID card and the JBOD-4U60 before configuration T10 zoning. After configuring T10 zoning, please power cycle the JBOD-4U60 and then insert the SAS cable back (SFF-8644).

After enabling T10 zoning, five predefined groups are Group1, Group8, Group9, Group10, and Group11.

- (A) Get current zoning of wide port 1

```
cmd> zone_port 1
Wideport 01 for Zone Group 01
```

- (B) Set the wideport 1 as Zone Group 8

```
cmd> zone_port 1 8
Succeeded to set zone group for the phy
```

3.3.11 How to configure zoning of the disk slot (EDGE only)

Remove the SAS cable(SFF-8644) between the HBA/RAID card and the JBOD-4U60 before configuration T10 zoning. After configuring T10 zoning, please power cycle the JBOD-4U60 and then insert the SAS cable back(SFF-8644).

After enabling T10 zoning, five predefined groups are Group1, Group8, Group9, Group10, and Group11.

- (A) Get current zoning of Disk Slot 10

```
cmd> zone_slot 10
Slot 10 for Zone Group 1.
```

- (B) Set Disk Slot 10 as Zone Group 8

```
cmd> zone_slot 10 8
Succeeded to set zone group for the phy
```

3.4 Vendor Specific Vital Product Data (VPD) Page

The Vendor Specific VPD pages provide MFR_ID, MFR_MODEL, MFR_REVISION, MFR_SERIAL, and MFR_FW_REVISION of the power module 0 (page code 0xC1) and power module 1 (page code 0xC2).

Vendor Specific VPD Page Format

BYTE/BIT	7	6	5	4	3	2	1	0
1	MFR_ID							
m								
m+1	0x20 (ASCII code space)							
m+2	MFR_MODEL							
n								
n+1	0x20 (ASCII code space)							
n+2	MFR_REVISION							
o								
o+1	0x20 (ASCII code space)							
o+2	MFR_SERIAL							
p								
p+1	0x20 (ASCII code space)							
p+2	MFR_FW_REVISION							
q								
q+1	0x20 (ASCII code space)							

Chapter 4. BMC Configuration Settings

4.1 Login

BMC console port

The RS232 setting - baud rate: 38400 bps, data bits: 8, parity: none, stop bits: 1, flow control: none

1. Push the "[" key, it will show the IPMI serial interface.

```
-----  
                IPMI  Terminal Interface  
-----  
Usage :  
Terminal Text command : [SYS Command]  
Terminal IPMI command : [NetFnLun SeqNum Cmd Data 0 ... Data N]  
  
Type [SYS HELP] - To get list of Text Command  
Press CTRL+X or CTRL+C - To exit Terminal  
  
IPMI Terminal:/> [█
```

Type command for login the interface.

#[sys pwd -u admin admin]

It will response [OK]

```
IPMI Terminal:/> [SYS PWD -U admin admin ]  
[OK]
```

2. Change user password.

Due to security principles, you need to change your password when logging in for the first time. There are 16 Bytes that can be filled with ASCII Hex, at least 8 Bytes with value, and the rest fill in 0.

Change the password to “12345678”:

```
IPMI Terminal:/> [18 00 47 02 02 31 32 33 34 35 36 37 38 00 00 00 00 00 00 00 ]  
[1C 00 47 00]
```

Retry to login the interface.

```
#[sys pwd -u admin 12345678 ]
```

It will response [OK]

```
IPMI Terminal:/> [SYS PWD -U admin 12345678 ]  
[OK]
```

3. Find LAN information.

0 _{hex}	=	0 _{dec}
1 _{hex}	=	1 _{dec}
2 _{hex}	=	2 _{dec}
3 _{hex}	=	3 _{dec}
4 _{hex}	=	4 _{dec}
5 _{hex}	=	5 _{dec}
6 _{hex}	=	6 _{dec}
7 _{hex}	=	7 _{dec}
8 _{hex}	=	8 _{dec}
9 _{hex}	=	9 _{dec}
A _{hex}	=	10 _{dec}
B _{hex}	=	11 _{dec}
C _{hex}	=	12 _{dec}
D _{hex}	=	13 _{dec}
E _{hex}	=	14 _{dec}
F _{hex}	=	15 _{dec}

Find LAN static IP /DHCP [30 00 02 01 04 00 00]

LAN static IP /DHCP: 01 is static IP and 02 is DHCP.

Find LAN IP [30 00 02 01 03 00 00]

Find submask [30 00 02 01 06 00 00]

Find gateway [30 00 02 01 0C 00 00]

```
IPMI Terminal:/> [30 00 02 01 04 00 00 ]
[34 00 02 00 11 02]
```

```
IPMI Terminal:/> [30 00 02 01 03 00 00 ]
[34 00 02 00 11 C0 A8 15 44]
```

```
IPMI Terminal:/> [30 00 02 01 06 00 00 ]
[34 00 02 00 11 FF FF FF 00]
```

```
IPMI Terminal:/> [30 00 02 01 0C 00 00 ]
[34 00 02 00 11 C0 A8 15 FE]
```

The red box represents hexadecimal digits. According to the left figure, the IP is $16 \times 12 + 0 = 192$, $16 \times 10 + 8 = 168$, $16 \times 1 + 5 = 21$, $16 \times 4 + 4 = 68$. Therefore, the IP is 192.168.21.68

4. Set LAN information.

Set LAN static IP /DHCP [30 00 01 01 04 01/02]

Set LAN IP [30 00 01 01 03 C0 A8 0B 0B]

Set submask [30 00 01 01 06 FF FF FF 00]

Set gateway [30 00 01 01 0C C0 A8 00 01]

```

IPMI Terminal:/> [30 00 01 01 04 01 ]
[34 00 01 00]

IPMI Terminal:/> [30 00 01 01 03 C0 A8 0B 0B ]
[34 00 01 00]

IPMI Terminal:/> [30 00 01 01 06 FF FF FF 00 ]
[34 00 01 00]

IPMI Terminal:/> [30 00 01 01 0C C0 A8 00 01 ]
[34 00 01 00]

```


The digit in the red box is completion code.

00 represents the confirmed code.

The digits in the green box are can be configured to any value.

If you want to change the IP address, you must set the **LAN status to static**.

5. Connect to RJ45 port. Set the local host IP to **192.168.11.xx** segment.
6. Open the web browser and enter default IP **http://192.168.11.11**. When the login window appears, set the user name and password from step 2.
7. Click Log In to continue.



4.2 Web UI

4.2.1 Introduction

The BMC (Baseboard Management Controller) permits remote networking access to multiple users situated in different locations. In addition to this, it facilitates remote system health monitoring and computer event management for system administrators.

4.2.2 Overview of the ASPEED AST2520 BMC

The ASPEED AST2520 is a powerful stand alone BMC chip with internal 800MHz ARM11 CPU and the mainstream double data rate memory migrating from DDR3 to DDR4. The BMC facilitates remote monitoring and management of systems.

4.2.3 AIC BMC Features

The BMC functions supported by AIC are as follows.

- Hardware monitoring
- Overall health status display on the main page
- Remote system power control
- Remote serial over LAN (text console)
- Event Log support
- Automatic notifications and alerts (SNMP and email)
- Out-of-band management via shared or dedicated LAN
- Change LAN interface options at runtime
- VLAN
- Factory default settings from web support
- OS independent
- System Lockdown
- Backup and restore the configuration file
- Update firmware via browser and OS
- Redfish

4.2.4 Applicable or Supported Platforms

This BMC firmware applies to 4U60 SAS12G JBOD series platforms.

4.2.5 Log In to the Remote Console

4.2.5.1 Required Browser Settings

Use a computer and configure its web browsers.

- Accept the file download when prompted in all browsers
- Javascript and cookie settings should be enabled in order to access the web site




NOTE

Cookies must be enabled in order to access the website.

4.2.5.2 Username and Password

The computer and BMC need to be on the same subnet. After setting the static IP, they should be able to communicate. To establish a connection, follow the steps below.

1. Use the computer's terminal to ping the BMC IP address and ensure that it can be pinged.
2. If the BMC IP address is pingable, open a web browser on your computer, enter the BMC IP address in the URL bar.



NOTE

AIC JBOD Default IP: 192.168.11.11

3. Initial access prompts you to enter the User Name and Password. A sample screenshot of the login screen is given below.

The fields are explained as follows:

Fields Name	Description
Username	Enter your username in this field.
Password	Enter your password in this field.
Language Selection	Language selection drop-down will be populated based on supported languages in Web UI as a part of multi-language support feature. Drop-down option value will be selected based on the browser language. For example, if browser language is configured with Simplified Chinese language (ZH-CN), then option value will be auto selected as China. Default language will be selected as US-English if the browser configured language not supported by Web UI. Entire Web UI pages language strings will be displayed based on selected language from drop-down.
Remember Username	Check this option to remember your login Username. If you select this option, the browser will save your credentials internally in its memory, and when you open that site the next time, it will auto-fill Username for you.
Sign me in	After entering the required credentials, click the Sign me in to login.
I forgot my password	If you forget your password, you can generate a new password using this link.

4.2.5.3 Default User Name and Password

Default Username: **admin**

Default Password: **admin**



NOTE

The default user name and password are in lower-case characters. When you log in using the user name and password, you get full administrative rights. It is advised to change your password once you login.

Duplicate user names shouldn't exist across various authentication methods like AD, LDAP, RADIUS or IPMI since the privilege of one Authentication method is overwritten by another authentication method when login and hence the correct privilege can not be returned properly. Duplicate user names shouldn't be existed across different channels in IPMI.

Warning:

Once you login to the application, it is recommended not to use the following options.


- Refresh button of the browser
- Refresh menu of the browser
- Back and Forward options of the browser
- F5 on the keyboard
- Backspace on the keyboard

The changes done in user account properties through IPMI/Redfish interfaces will not be reflected in current active web sessions.

4.2.5.4 Need to change password

It is mandatory to change the password for the default user at first successful login due to California Law SB-327 security fix. If the authentication is successful, then Web UI will prompt a new page which will ask to change the user password. Once the password is changed, login page will be reloaded. Enter the username and modified password to Login.

A sample screenshot is given below.

The screenshot shows a web interface for the 'AIC BMC System'. At the top is a green header with the text 'AIC BMC System'. Below the header is a light gray box containing a blue message: 'Password should be changed for default user and should have a minimum of 8 characters.' Underneath the message are two white input fields with gray borders. The first field is labeled 'New Password' and the second is labeled 'Confirm Password'. Below these fields is a green button with the text 'Submit' in white.

Default User's password can be changed using any of the following method.

- Web UI
- IPMI Tool
- Redfish (If Redfish Support is enabled)

**NOTE**

The last password used cannot be used to reset the password.

Password Change Required Case

1. When the BMC boots with factory firmware, user needs to change the default password on first boot.
2. When the user upgrades the BMC firmware without preserving the configuration, default pass word needs to be changed on the first boot.
3. When the user restores factory settings and restarts the BMC, the default password needs to be changed during the restart.
4. Whenever the user detects BMC configuration corruption and restores the configuration to factory settings, the default password needs to be changed on the next boot.

Limitations

If the current Firmware in BMC is without CA law enabled and the default password is modified and user tries to preserve configuration and upgrade firmware with CA law enabled firmware image, BMC will still prompt to change the user password.

Reason

In BMC firmware default password is not preserved or stored anywhere, so it is not possible to check if the default password is modified or not. Default password can also be modified during Build time in PMCP file as required by OEM.

**NOTE**

Since Password Change at first login is made as PRJ configurable and if this feature is disabled then it is not mandatory to change the default password at first login.

4.2.6 Menu Bar and Quick Button


4.2.6.1 Menu Bar

The menu bar displays the following.

Firmware Information will be displayed with the latest version, date and time details.


Power Control Status will be displayed as Host Online. To change the Power Control Status, click [Host Online](#) link. Accept the file download when prompted in all browsers Javascript and cookie settings should be enabled in order to access the web site

- Dashboard
- Sensor
- FRU Information
- PSU Information
- Logs & Reports
- Settings
- Remote Control
- Chassis Identify
- HDD Management
- Power Control
- Maintenance
- Sign out



4.2.6.2 Quick Button and Logged-in User

The user information and quick buttons are located at the top right. A screenshot of the logged-in user information is shown below.



The logged-in user information shows the logged-in user, his/her privilege and the four quick buttons allowing you to perform the following functions.

Logged-in user and its privilege level

This option shows the logged-in user name and privilege. There are five kinds of privileges.

1. **User:** Only valid commands are allowed.
2. **Operator:** All BMC commands are allowed except for the configuration commands that can change the behavior of the out-of-hand interfaces.
3. **Administrator:** All BMC commands are allowed.
4. **No Access:** Login access denied.
5. **OEM:** All OEM commands are allowed.

Message: Click the  icon to view the event log alert messages. On clicking the messages, it will navigate to the Logs and Reports page.

Notification: Click  to view the notification received.

Language Selection: Change the language to view the language strings in different languages.

Refresh: Click the  Refresh icon or pressing key F5 to reload the current page.

Sync: Click the  Sync icon to synchronize with Latest Sensor and Event Log updates.

Sign out: Click the  icon to log out of the MegaRAC GUI.


Quick Search: Quick Search is a short-cut for the available menu and sub-menu pages. It displays available search queries. Click  (Quick Search) field, and type search terms of the lists in the menu bar. As you type, the suggestions will be displayed in a drop-down list below the Quick Search field as a navigational links of the menu and sub- menu. On selecting your search term from the drop-down list, it will directly go to the specific page which you have searched.

Help: The Help icon () is Located at the top right of each page in MegaRAC GUI. Click this help icon to view more detailed field descriptions

4.2.7 Dashboard

The Dashboard page gives the overall information about the status of a device.

To open the Dashboard page, click [Dashboard](#) from the menu bar. A sample screenshot of the Dashboard page is shown below.



A brief description of the Dashboard page is given below.

BMC Power-On Hours

BMC Power-On Hours will keep on accumulated.

Pending Deassertions

It lists all the asserted events which are waiting for deassert state. To know about the pending events details, click the More info link. This navigates to the Event Log page and display all the asserted events that are waiting for deassertion.

Access Logs

A graphical representation of all events incurred by various sensors and occupied/available space in logs can be viewed. If you click on the More info link, you can view the Audit Log page.

Today & 30 Days (Event Logs)


This page displays the list of event logs occurred by the different sensors on this device. Click Details link on Today and 30 days to view the event logs for Today and 30 days respectively.

Sensor Monitoring

It lists all the critical sensors on the device. If you click on any list sensor, you can view the Sensor detail page with the Sensor information and Sensor Events details.

4.2.8 Sensor

The Sensor Reading page displays all the sensor related information. To open the Sensor Reading page, click [Sensor](#) from the menu. Click on any sensor to show more information about that particular sensor, including thresholds and a graphical representation of all associated events. A screenshot of Sensor Reading page is given below.




Sensor Readings Page

The Sensor Readings page contains the following information. In this Sensor Reading page, Live readings for all the available sensors with details like Sensor Name, Status, Current Reading and Behavior will be appeared, else you can choose the sensor type that you want to display from the list. Some examples for sensors are Temperature Sensors and Fan Sensors etc.

Sensor Detail

Select a particular Sensor from the Critical Sensor or Normal Sensor lists. The Sensor Information as Live Widget and Thresholds for the selected sensor will be displayed as shown below.



Sensor detail

For the selected sensor, this widget gives a dynamic representation of the readings for the sensor.

Thresholds are of six types:

- Lower Non-Recoverable (LNR)
- Lower Critical (LC)
- Lower Non-Critical (LNC)
- Upper Non-Recoverable (UNR)
- Upper Critical (UC)
- Upper Non-Critical (UNC)



NOTE

Widgets are little gadgets, which provide real time information about a particular sensor. User can track a sensor's behavior over a specific amount of time at specific intervals. The result will be displayed as a line graph in the widget. The session will not expire, until the widgets gets a live data of the last widget that is kept opened.

The threshold states could be

- Lower Non-critical - going low
- Lower Non-critical - going high
- Lower Critical - going low
- Lower Critical - going high
- Lower Non-recoverable - going low
- Lower Non-recoverable - going high
- Upper Non-critical - going low
- Upper Non-critical- going high
- Upper Critical - going low
- Upper Critical - going high
- Upper Non-recoverable - going low
- Upper Non-recoverable - going high

View this Event Log

You can click [here](#) to view the Logs & Reports for the selected sensor.

4.2.9 FRU Information

FRU Information page displays the BMC's FRU device information. FRU page shows information like Basic Information, Chassis Information, Board Information and Product Information of the FRU device.

To open the FRU Information page, click [FRU Information](#) from the menu bar. Select a FRU Device ID from the FRU Information section to view the details of the selected device. A screenshot of FRU Information page is given below.

The screenshot displays the 'FRU Field Replaceable Units' page. At the top, there's a header with a menu icon, language selector (US - English), and user profile (admin). Below the header, the page title 'FRU Field Replaceable Units' is shown. The main content area is divided into sections. The 'Available FRU Devices' section contains a dropdown for 'FRU Device ID' and a text field for 'FRU Device Name' with the value 'BMC_FRU'. Below this, there are three columns of information: 'Chassis Information', 'Board Information', and 'Product Information'. Each column has a table of fields and values.

Chassis Information		Board Information		Product Information	
Chassis Information Area Format Version	1	Board Information Area Format Version	1	Product Information Area Format Version	1
Chassis Type	Main Server Chassis	Language	0	Language	0
Chassis Part Number		Manufacture Date Time	Tue Sep 18 14:32:00 2018	Product Manufacturer	
Chassis Serial Number		Board Manufacturer	AIC	Product Name	
Chassis Extra		Board Product Name	VIRGO	Product Part Number	
		Board Serial Number	35992-1837-00043	Product Version	
		Board Part Number	BMB-DPS0002B	Product Serial Number	
		FRU File ID		Asset Tag	
		Board Extra		FRU File ID	
				Product Extra	

FRU Information Page

The following fields are displayed here for the selected device.

Available FRU Devices

- FRU device ID - Select the device ID from the drop down list
- FRU Device Name - The device name of the selected FRU device.

Chassis Information

- Chassis Information Area Format Version
- Chassis Type
- Chassis Part Number
- Chassis Serial Number
- Chassis Extra

Board Information

- Board Information Area Format Version
- Language
- Manufacture Date Time
- Board Manufacturer
- Board Product Name
- Board Serial Number
- Board Part Number
- FRU File ID
- Board Extra

Product Information

- Product Information Area Format Version
- Language
- Product Manufacturer
- Product Name
- Product Part Number
- Product Version
- Product Serial Number
- Asset Tag
- FRU File ID
- Product Extra

4.2.10 PSU Information

PSU Information page displays the BMC's Power Supply Unit information. This page shows information like Status, Sensor Reading and Model Details of the PSU.

To open the PSU Information page, click [PSU Information](#) from the menu bar. A screenshot of PSU Information page is given below.

Slot 1		Slot 2	
Power Supply Status	PS OK	Power Supply Status	PS OK
AC Input Voltage	123 V	AC Input Voltage	123 V
AC Input Current	0.515 A	AC Input Current	0.500 A
DC 12V Output Voltage	12.1 V	DC 12V Output Voltage	12.1 V
DC 12V Output Current	4.250 A	DC 12V Output Current	3.500 A
Temperature 1	33.0 C/91.0 F	Temperature 1	35.0 C/95.0 F
Temperature 2	36.0 C/96.0 F	Temperature 2	39.0 C/102.0 F
Fan 1	7392 RPM	Fan 1	7456 RPM
DC 12V Output Power	48 W	DC 12V Output Power	42 W
AC Input Power	60 W	AC Input Power	56 W
Model	R1CA2801A	Model	R1CA2801A
Serial Number	FSE052A0400C GB2202000877	Serial Number	FSE052A0400C GB2202000833
FW Rev	04 08 01 00	FW Rev	04 08 01 00

PSU Information Page



NOTE


If the device is not detected successfully, please turn on the power or reinstall the device.

4.2.11 Logs & Reports

To open the Logs & Reports page, click Logs & Reports from the menu bar. The Logs & Reports page displays the following information.

- IPMI Event Log
- System Log


A screenshot displaying the menu items under Logs & Reports is shown below



4.2.11.1 IPMI Event Log

This page displays the list of event logs occurred by the different sensors on this device. Double click on a record to see the details of that entry. You can use the sensor type or sensor name filter options to view those specific events or you can also sort the list of entries by clicking on any of the column headers.

To open the Event Log page, click [Logs & Reports > Event Log](#) from the menu bar. A sample screenshot of Event Log page is shown below.



Event Log Page

The Event Log page consists of the following Fields.

Filter By Date: Filtering can be done by selecting Start Date and End Date using Calendar.



NOTE

Date should be in MM/DD/YYYY format. By default, all log time will be displayed in BMC time zone.

Filter By Type: The category could be either All Events, System Event Records, OEM Event Records, BIOS Generated Events, SMI Handler Events, System Management Software Events, System Software - OEM Events, Remote Console Software Events, Terminal Mode Remote Console software Events.



NOTE

Once the Filter By Date and Filter type are selected, the list of events will be displayed with the Event ID, Time Stamp, Sensor Type, Sensor Name and Description.

UTC Offset: Displays the current UTC Offset value based on which event Time Stamps will be updated. Navigational arrows can be used to selectively access different pages of the Event Log.

Event Log Statistics: Displays the statistical graph for the selected date.

Clear Event Logs: To delete all the event logs.

Download Event Logs: To download the event logs.

Procedure

1. From the Filter By Date field, select the time period by Start Date and End Date using Calendar for the event categories. The events will be displayed according to the selected date.
2. From the Filter By Type field, select the Type of the event and Sensor name to view the events for the date. The events will be displayed based on the selected time period.
3. To clear all events from the list, click Clear All Event Logs.
4. To download the event logs, click Download Event Logs.



NOTE

When Clear All Event Logs action is performed, there might be some events present even after clearing those events are generated after performing clear operation which can be verified using its time stamp.

4.2.11.2 Audit Log


Audit Log page will display all the system events occurred in this device that has been already configured.



NOTE

Logs have to be configured under **Settings -> Log Settings -> Advanced Log Settings** in order to display any entries.

To open the Event Log page, click [Logs & Reports > Audit Log](#) from the menu bar. A sample screenshot of Audit Log page is shown below.




Procedure

To view Audit Log, click the Audit Log tab to view all audit events for this device.

4.2.12 Settings

To open the Settings page, click [Settings](#) from the menu bar. This group of pages allows you to access various configuration settings. A screenshot of Configuration Group menu is shown below.



Configuration Group Menu

- Date & Time
- Log Settings
- Network Settings
- Platform Event Filter
- Services
- SMTP Settings
- System Firewall
- User Management
- Power Restore Policy
- Zone Configurations

A detailed description of the Configuration menu is given below.

4.2.12.1 Date & Time

This field is used to set the date and time on the BMC. A sample screenshot of Date & Time is shown as below.

The screenshot displays the 'Date & Time' configuration interface. At the top, a breadcrumb trail shows 'Home > Settings > Date & Time'. A note states: 'Note: If the timezone is selected from the group of Manual offset(GMT/ETC timezones), • The map selection will be disabled. • The TimeZone settings will be reflected only after saving the settings.' The main section, 'Configure Date & Time', features a world map. Below the map, a dropdown menu is set to 'America/Manaus', and the current time is shown as 'Jun 23, 2017 6:38:44 AM (GMT-04:00 AMT) - America/Manaus'. A checkbox labeled 'Automatic NTP Date & Time' is checked. Below this, there are two input fields: 'Primary NTP Server' with the value 'pool.ntp.org' and 'Secondary NTP Server' with the value 'time.nist.gov'. A 'Save' button is located at the bottom right of the form.

Date & Time - Automatic Date & Time

The Date & Time section consists of the following fields.

Configure Date & Time: Displays Time zone list containing the UTC offset along with the locations and Navigational line to select the location which can be used to display the exact local time.

Select Time Zone: This field is used to set the date and time on the BMC.

Automatic Date & Time: To automatically synchronize Date and Time with the NTP Server.

Primary NTP Server: To configure a primary NTP server to use when automatically setting the date and time.

Secondary NTP Server: To configure a secondary NTP server to use when automatically setting the date and time.

Save: To save the settings.




NOTE

If the time zone is selected as Manual Offset, the map selection will be disabled. The Time Zone settings will be reflected only after saving the settings.

**NOTE****RTC Board**

RTC board enables you to use a real-time-clock and calendar in your applications. The real-time clock is driven by a special battery that is not connected to the normal power supply. As following are some notes for the RTC board settings.

1. Please manually set the accurate time for the first time.
2. When you select "Automatic NTP Date & Time", it only automatically update the time on BMC. Meanwhile, the time of the RTC board will not be updated.
3. Remember to calibrate the RTC board as current time after a period of use.




Disable Automatic Date & Time Option

User can modify the Date and Time manually by disabling the Automatic Date and Time option.

This will provide option to choose time, time zone and date manually.

This Web GUI provides two options to modify the Date and Time.


1. We can choose Interactive map section to update the time and time zone. If we choose the time zone from interactive map section, the time will update accordingly with the time zone.



Date&Time - Automatic Date & Time Disabled


If we change the time zone, the time will be modified by their time zone reference. Still if the user want to modify the date and time, the user can click the clock icon on Web UI to modify the date and time.

2. We can choose the time zone from the group of Manual Offset. If the time zone is selected from the group of Manual offset (GMT/ETC time zones), then interactive map selection feature will be disabled. The user has to manually modify the Date and Time from the user web GUI. To manually modify Date and Time, click on clock icon.



Configure Date & Time Manually

The User can modify the Date and Time using this option. If we click on the calendar icon option to change, Date will be visible to the user.



Option to Change Date

Procedure

1. Select the Timezone location either using drop down or Map.
2. Enable Automatic Date & Time option to enable/disable the use of NTP servers to automatically set the date and time.
 - a. In the Primary NTP Server and Secondary NTP Server fields, specify the NTP servers of the device respectively.



NOTE

Secondary NTP server is optional field.


If the Primary NTP server is not working fine, then the Secondary NTP Server will be tried.

3. Click Save button to save the settings.

4.2.12.2 Log Settings

Logs and Reports page displays a list of IPMI Event logs and audit logs occurred in this device.

To open Log Settings page, click [Settings > Log Settings](#) from the menu bar. A sample screenshot of Log Settings page is shown below.



The fields of Log Settings page are explained below.

- SEL Log Settings Policy
- Advanced Log Settings

4.2.12.2.1 SEL Log Setting Policy

To open Log Settings page, click [Settings > Log Settings > SEL Log Settings Policy](#) from the menu bar. A sample screenshot of SEL Log Settings Policy page is shown below.



This page is used to configure the log policy for the event log. The fields are as followed

Log Policy: This field is to enable or disable the Linear Storage Policy or Circular Storage Policy.

Save: To save the configured settings

4.2.12.2.2 Advanced Log Settings

To open Advanced Log Settings page, click [Settings > Log Settings > Advanced Log Settings](#) from the menu bar. A sample screenshot of **Advanced Log Settings Policy** page is shown below.

The screenshot shows the 'Advanced Log Settings' page. At the top, there's a navigation bar with 'Home > Settings > Log Settings > Advanced Log Settings'. The main content area has a title 'Advanced Log Settings' and a green question mark icon. Below this is a form with the following fields:

- ☒ System Log
- ☒ Local Log
- ☐ Remote Log
- Port Type: ☒ UDP ☐ TCP
- File Size:
- Rotate Count:
- Remote Log Server:
- Remote Server Port:
- ☒ Enable Audit Log

A 'Save' button is located at the bottom right of the form.

This page is used to configure the log policy for the event log. The fields are as followed.

System Log: This field is used to enable or disable the System Log. Select **System Log** to view all system events. Entries can be filtered based on their classification levels. Specifies the Location for system logs, whether it should be preserved in a **Local Log/Remote Log**.

Local Log: Select Local Log to save the logs locally (BMC).

Rotate Count: To back up the log information in back up files.



NOTE

Values supported are 0 and 1.

Remote Log: Select Remote Log to save the logs in a remote machine.



NOTE

- You can select either Local Log/Remote Log or both Logs as per the requirement.
- Either one of the Log selection is mandatory.
- Local file resides at /var/log/

Remote Log Server: This field is to specify the Remote server address to log the system events.

**NOTE**

Server address will support the following:

- IPv4 address format.
- FQDN (Fully qualified domain name) format.
- Maximum allowed size is 64 bytes.

Port Type: Port Type is supported with the enable of Remote Log. You can select either UDP/TCP as per the requirement.

File Size: This field is to specify the size of the file in bytes if the selected log type is local.

**NOTE**

Size ranges from 3 to 65535. Log files are rotated when they grow bigger than size bytes mentioned, with regards for the last rotation time interval (1 minute).

Remote Server Port: This field is to specify the Remote Server port address to log the system events.

**NOTE**

Remote Log Server and Remote Server Port options will be available only when Remote Log is enabled.

Enable Audit Log: To enable or disable the audit log.

Save: To save the changes

Procedure

1. In the System Log field, enable or disable the option.
2. Select the Log type: Local Log or Remote Log.
3. If Local log is selected, enter the file size in the File Size field and rotate count in the Rotate Count field.

**NOTE**

If Remote log is selected, the fields file size and rotate count need not be mentioned.

4. If remote log is selected, specify the Server Address of the remote server where the system events are logged.
5. In the Audit Log field, check or uncheck the Enable option as desired.
6. Click Save to save the changes.

Steps to configure the remote server to enable syslogging**NOTE**

This example uses FC13 as the remote machine to log syslog. On FC machine, disable the following lines for UDP in /etc/rsyslog.conf.

1. MODLOAD imudp
2. UDPSERVER 514

4.2.12.3 Network Settings

The Network Settings page is used to configure the network settings for the available LAN channels.

4.2.12.3.1 Network IP Settings

To open Network Settings page, click [Settings -> Network Settings -> Network IP Settings](#) from the menu bar. A sample screenshot of **Network IP Settings** Page is shown below.

The fields of Network IP Settings page are explained below.

Enable LAN: To enable or disable the LAN Settings.

LAN Interface: Lists the LAN interfaces.

MAC Address: This field displays the MAC Address of the device. This is a read only field.

Enable IPv4: This option is to enable/disable the IPv4 settings in the device.

Enable IPv4 DHCP: This option is to enable IPv4 DHCP support for the selected interface.

IPv4 Address, IPv4 Subnet Mask, and IPv4 Default Gateway: These fields are for specifying the static IPv4 address, Subnet Mask and Default Gateway to be configured to the device.



NOTE

- IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx".
- Each Number ranges from 0 to 255.
- First Number must not be 0.

Enable IPv6: To Enable/Disable the IPv6 configuration settings.

Enable IPv6 DHCP: To Enable/Disable the IPv6 settings in the device. It dynamically configures IPv6 address using DHCP (Dynamic Host Configuration Protocol).

IPv6 Index: To specify a static IPv6 Index to be configured to the device. E.g.: 0.

IPv6 Address: To specify a static IPv6 address to be configured to the device. Eg: 2004::2010.

Subnet Prefix length: To specify the subnet prefix length for the IPv6 settings.



NOTE

Value ranges from 0 to 128.

Default Gateway: Specify v6 default gateway for the IPv6 settings.



NOTE

If core feature IPV6_COMPLIANCE and SUPPORT_IPMIIPV6_LAN_PARAM_ONLY are enabled, the IPv6 default Gateway field will not be displayed.

Clear IPv6 Address: This field will be displayed to clear the IPv6 address only if the IPv6 address and Subnetwork Prefix Length is available for the selected index value.

Enable VLAN: To enable/disable the VLAN support for selected interface.

VLAN ID: The Identification for VLAN configuration.



NOTE

Value ranges from 2 to 4094.

VLAN Priority: The priority for VLAN configuration.



NOTE

- Value ranges from 0 to 7.
- 7 is the highest priority for VLAN.

Save: To save the entries.

Procedure

1. Check Enable LAN to enable LAN support for the selected interface..
2. Select the LAN Interface to be configured.
3. Check Enable IPv4 to enable IPv4 support for the selected interface.
4. Check Enable IPv4 DHCP to dynamically configure IPv4 address using DHCP.
5. If the field is disabled, enter the IPv4 Address , IPv4 Subnet Mask and IPv4 Default Gateway in the respective fields.
6. In IPv6 Configuration, if you wish to enable the IPv6 settings, check Enable IPv6.
7. If the IPv6 setting is enabled, enable or disable the option Enable IPv6 DHCP.
8. If the field is disabled, enter the IPv6 Address, Subnet Prefix length and IPv6 Index in the given field.
9. In VLAN Configuration, if you wish to enable the VLAN settings, check Enable LAN.

10. Enter the VLAN ID in the specified field.
11. Enter the VLAN Priority in the specified field.
12. Click Save to save the entries.

4.2.12.3.2 Network Link Configuration

This page is used to configure the network link configuration for available network interfaces.

To open **Network Link** page, click [Settings > Network Settings > Network Link](#) from the menu bar. A sample screenshot of **Network Link Configuration** page is shown below.

The fields of Network Link Configuration page are explained below.

LAN Interface: Select the required network interface from the list to which the Link speed and duplex mode to be configured.

Auto Negotiation: This option is enabled to allow the device to perform automatic configuration to achieve the best possible mode of operation (speed and duplex) over a link.

Link Speed: Link speed will list all the supported capabilities of the network interface. It can be 10/100/1000 Mbps.



NOTE

Link speed of 1000 Mbps is not applicable, when Auto Negotiation is OFF.

Duplex Mode: Duplex Mode could be either Half Duplex or Full Duplex.

Save: To save the settings.

Procedure

1. Select the LAN Interface from the drop down list.
2. Select either Enable or Disable for Auto Negotiation.

**NOTE**

The Link Speed and Duplex Mode will be active only when Auto Negotiation is OFF.

3. Select the **Link Speed** from the drop-down list.
4. Select the Duplex Mode either **Full duplex** or **Half duplex**.
5. Click **Save** to save the configuration.

4.2.12.3.3 DNC Configuration

The **Domain Name System (DNS)** is a distributed hierarchical naming system for computers, services, or any resource connected to the Internet or a private network. It associates the information with domain names assigned to each of the participants. Most importantly, it translates domain names meaningful to humans into the numerical (binary) identifiers associated with networking equipment for the purpose of locating and addressing these devices worldwide.

The DNS Server settings page is used to manage the DNS settings of a device.

To open DNS Server Settings page, click [Settings](#) > [Network Settings](#) > [DNS Configuration](#) from the menu bar. A sample screenshot of DNS Configuration page is shown below.

The fields of DNS Configuration page are explained below.

Domain Name Service Configuration

DNS Enabled: To enable/disable all the DNS Service Configurations.

mDNS Enable: To enable/disable the mDNS Support Configurations.

Host Name Settings: Choose either Automatic or Manual settings.

Host Name: It displays host name of the device. If the Host setting is chosen as Manual, then specify the host name of the device.



NOTE

- Value ranges from 1 to 64 alpha-numeric characters.
- Special characters '-'(hyphen) and '_'(underscore) are allowed.
- It must not start or end with a '-'(hyphen). IE browsers won't work correctly if any part of the host name contain underscore (_) character.

BMC Registration Settings

BMC Interface: Options to register the BMC through the Interfaces.

Register BMC: To register BMC through registration method.

Registration Method

Options to register the BMC are through **NS Update** or **DHCP Client FQDN** or **Hostname**.

TSIG Configuration

Both: Check this option to modify TSIG authentication for both interfaces.

Eth 0&1:

- **TSIG Authentication Enabled:** Check this box to enable TSIG authentication while registering DNS via nsupdate. Separate TSIG files can be uploaded for each LAN interface.
- **Current TSIG Private File:** The information of Current TSIG private file along with its uploaded date/time will be displayed (read-only).
- **New TSIG Private File:** Browse and navigate to the TSIG private file.



NOTE

TSIG file should be of private type.

Domain Setting: Select whether the domain interface will be configured manually or automatically.

- **Automatic** - If you Select **Automatic**, the Domain Name cannot be configured as it will be done automatically. The field will be disabled.
- **Manual** - If the Domain setting is chosen as **Manual**, then specify the domain name of the device.



NOTE

If you select "Automatic" it displays the Domain Interface option. If you select "Manual" it displays "Domain name"

- **Domain Name:** It displays the domain name of the device.

Domain Name Server Setting

Automatic - If you select Automatic “DNS Interface” option should be explained.

Manual - Specify the DNS (Domain Name System) server address to be configured for the BMC.

IP Priority:

- If IP Priority is **IPv4**, it will have 2 IPv4 DNS servers and 1 IPv6 DNS server.
- If IP Priority is **IPv6**, it will have 2 IPv6 DNS servers and 1 IPv4 DNS server.



NOTE

This is not applicable for Manual configuration.

DNS Server 1, 2 & 3

To specify the DNS (Domain Name System) server address to be configured for the BMC.



NOTE

- IPv4 Addresses should be given in dotted decimal representation.
- IPv6 Addresses are supported and must be global unicast addresses.

DNS Server Address will support the following:

- IPv4 Address format.
- IPv6 Address format.

Save: To save the entered changes.

Procedure

1. In Domain Name Service Configuration, Enable DNS Service.
 - Check the option DNS Enabled to enable all the DNS Service Configurations.
2. Choose the Host Name Setting either Automatic or Manual.



NOTE

If you choose Automatic, you need not enter the Host Name and if you choose Manual, you need to enter the Host Name.

3. Enter the Host Name in the given field if you have chosen Manual Configuration.
4. Under Register BMC, choose the BMC's network port to register with DNS settings.
Check Register BMC option to register with DNS settings.
 - Nsupdate - Choose Nsupdate option to register with DNS server using nsupdate application.
 - DHCP Client FQDN - Choose DHCP Client FQDN option to register with DNS Server using DHCP option.
 - Hostname - Choose Hostname option to register with DNS server using DHCP option.

**NOTE**

Hostname option should be selected, if the DHCP client FQDN option is not supported by DHCP server.

Hostname option is not support at DHCPv6, hence IPv6 will not register to DNS server at option hostname.

5. Check **Both** option to modify TSIG authentication for both interfaces (eth0&1).
6. In **Eth 0&1 TSIG Configuration**, Check **TSIG Authentication Enabled** option to enable/disable TSIG authentication while registering DNS via nsupdate.
 - The current file name will be displayed in **Current TSIG Private file info** field.
 - To view a new one, click **New TSIG private file** to browse and navigate to the TSIG private file.
7. In the Domain Settings
 - Select the domain settings (Automatic or Manual).
 - Enter the **Domain Name** in the given field if the option “**Manual**” is being selected in domain settings field.
8. In Domain Name Server Setting
 - Select the **DNS Name Server Setting**.
 - Choose the IP Priority, either IPv4 or IPv6.
 - Enter the DNS Server address.
9. In DNS Server1, DNS Server2 and DNS Server3, enter the server addresses to be configured for the BMC.
10. Click **Save** to save the entries

4.2.12.4 Platform Event Filter

Platform Event Filter (PEF) provides a mechanism for configuring the BMC to take selected actions on event messages that it receives or has internally generated. These actions include operations such as system power-off, system reset, as well as triggering the generation of an alert.

The PEF Management is used to configure the following


- Event Filters
- Alert Policies
- LAN Destinations

To open PEF Management Settings page, click [Settings > Platform Event Filter](#) from the menu bar. Each tab is explained below.

4.2.12.4.1 Event Filters

A PEF implementation is recommended to provide at least 40 entries in the event filter table. A subset of these entries should be pre-configured for common system failure events, such as over-temperature, power system failure, fan failure events, etc. Remaining entries can be made available for 'OEM' or System Management Software configured events.

Note that individual entries can be tagged as being reserved for system use - so this ratio of pre-configured entries to run-time configurable entries can be reallocated if necessary.



Platform Event Filters

The fields of Platform Event Filters Tab are explained below.

This page contains Pre-configured 40 Events with PEF IDs. Click Delete icon (✕) on the top right corner to directly delete an item from the list.

Procedure:

1. Click the **Event Filters** section to configure the event filters in the available slots.
2. To Add an Event Filter entry, select a free section to open the Event Filter entry Page. A sample screenshot of Event Filter Configuration page is shown below.

US - English

Sync

Refresh

admin

Home > Settings > Platform Event Filters > Event Filters > Event Filter Configuration

Event Filter Configuration

?

☐ Enable this filter

Event severity to trigger

Any severity

☒ Event Filter Action Alert

Power Action

None

Alert Policy Group Number

1

☒ Raw Data

Generator ID 1

255

Generator ID 2

255

Generator Type

☐ Slave ☐ Software

Slave Address/Software ID

Channel Number

0

IPMB Device LUN

0

Sensor type

All Sensors

Sensor name

All Sensors

Event Options

All Events

Event trigger

255

Event Data 1 AND Mask

0

Event Data 1 Compare 1

0

Event Data 1 Compare 2

0

Event Data 2 AND Mask

0

Event Data 2 Compare 1

0

Event Data 2 Compare 2

0

Event Data 3 AND Mask

0

Event Data 3 Compare 1

0

Event Data 3 Compare 2

0

Delete

Save

Event Filter Configuration

In the **Event Filter Configuration** section,

- In **Enable this filter**, check this option to enable the PEF settings.
- In **Event Severity to trigger**, select any one of the Event severity from the list.
- **Event Filter Action Alert**: It is checked by default. This action enables PEF Alert action (read-only).
- Select any one of the **Power Action** either Power down, Power reset or Power cycle from the drop down list
- Choose any one of the configured **Alert Policy Group Number** from the drop down list.



NOTE

Alert Policy has to be configured - under Settings->PEF->Alert Policy.

- Check **Raw Data** option to fill the Generator ID with raw data.
- **Generator ID 1** field is used to give raw generator ID1 data value.



NOTE

In **RAW** data field, specify hexadecimal value prefix with '0x'.

- **Generator ID 2** field is used to give raw generator ID2 data value.
- In the **Event Generator** section, choose the event generator as Slave Address - if event was generated from IPMB. Otherwise as System Software ID - if event was generated from system software.
- In the **Slave Address/Software ID** field, specify corresponding I2C Slave Address or System Software ID.
- Choose the particular **Channel Number** that event message was received over. Or choose '0' if the event message was received via the system interface, primary IPMB, or internally generated by the BMC.
- Choose the corresponding **IPMB Device LUN** if event generated by IPMB.
- Select the **Sensor Type** of sensor that will trigger the event filter action.
- In the **SensorName** field, choose the particular sensor from the sensor list.
- Choose **Event Option** to be either All Events or Sensor Specific Events.



NOTE

Value ranges from 1 to 255.

- **Event Trigger** field is used to give Event/Reading type value.
- **Event Data 1 AND Mask** field is used to indicate wildcarded or compared bits.



NOTE

Value ranges from 0 to 255.

- **Event Data 1 Compare 1 & Event Data 1 Compare 2** fields are used to indicate whether each bit position's comparison is an exact comparison or not.




NOTE

Value ranges from 0 to 255.

- **Event Data 2 AND Mask** field is similar to Event Data 1 AND Mask.
 - **Event Data 2 Compare 1 & Event Data 2 Compare 2** fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.
 - **Event Data 3 AND Mask** field is similar to Event Data 1 AND Mask.
 - **Event Data 3 Compare 1 & Event Data 3 Compare 2** fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.
3. Click **Save** to save the changes and return to event filter list.
 4. Click **Delete** to delete the existing filter.

4.2.12.4.2 Alert Policies

This page is used to configure the Alert Policy for the PEF configuration. You can add, delete or modify an entry in this page.



Platform Event Filters – Alert Policies

The fields of Platform Event Filter – Alert Policies section are explained below.

Policy Group Number: Displays the Policy number of the configuration.

Enable this alert: To enable or disable the policy settings.

Policy Action: To choose any one of the Policy set values (0-5) from the list.

0 - Always send alert to this destination.

1 - If alert to previous destination was successful, do not send alert to this destination.
Proceed to next entry in this policy set.

2 - If alert to previous destination was successful, do not send alert to this destination.
Do not process any more entries in this policy set.

3 - If alert to previous destination was successful, do not send alert to this destination.
Proceed to next entry in this policy set that is to a different channel.

4 - If alert to previous destination was successful, do not send alert to this destination.
Proceed to next entry in this policy set that is to a different destination type.

LAN Channel: To choose a particular channel from the available channel list.

Destination Selector: To choose a particular destination from the configured destination list.



NOTE

LAN Destination has to be configured under Settings → Platform Event Filters → LAN Destinations.

Event Specific Alert String: To specify an event-specific Alert String.

Alert String Key: To specify which string is to be sent for this Alert Policy entry.

Save: To save the Alert Policies entries.

Delete: To delete the selected configured Alert Policy.

Procedure

1. In the Alert Policies Section, select the slot for which you have to configure the Alert policy. That is, In the Alert Policies page, if you have chosen Alert Policy Group Number as 4, you have to configure the 4th slot (the slot with Policy Number 4) in the Alert Policy Tab.
2. Select the slot and click on the empty slot to open the Alert Policies page as shown in the screenshot below.

3. Select **Policy Group Number** from the drop-down list.
4. Check **Enable this alert** to enable the policy settings.
5. Choose any of the **Policy Action** from the list.
6. Choose particular **LAN Channel** from the available channel list.
7. In the **Destination Selector**, choose particular destination from the configured destination list.



NOTE

LAN Destination has to be configured under Settings → Platform Event Filters → LAN Destinations. That is if you select the number 4 for destination selector in Alert Policy Entry page, then you have to configure the 4th slot (LAN Destination Number 4) in the LAN Destinations tab.

8. Enable **Event Specific Alert String**, if the Alert policy entry is Event Specific .
9. In the Alert String Key field, choose any one value that is used to look up the Alert String to send for this Alert Policy entry.

**NOTE**

Using Web UI, Alert strings cannot be configured but option for Event Specific alert strings can be enabled/disabled. There is an option to select only the alert string keys, but alert strings has to be configured using IPMI Command (Set PEF Config Parameter "Alert String"). # and ; symbols are not supported for PEF Alert string.

10. Click **Save** to save the new alert policy and return to Alert Policy list.
11. Click **Delete** to delete a configuration.

4.2.12.4.3 LAN Destinations

This page is used to configure the LAN destinations of PEF configuration. A sample screenshot of LAN Destination Page is given below.

Home
>
Settings
>
Platform Event Filters
>
LAN Destinations

Select the LAN Channel
1

LAN Channel: 1 LAN Destination: 1 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 2 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 3 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 4 SNMP Trap Sent To:
LAN Channel: 1 LAN Destination: 5 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 6 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 7 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 8 SNMP Trap Sent To:
LAN Channel: 1 LAN Destination: 9 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 10 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 11 SNMP Trap Sent To:	LAN Channel: 1 LAN Destination: 12 SNMP Trap Sent To:

Platform Event Filters LAN Destinations

The fields of **Platform Event Filter** – LAN Destinations are explained below.

Select any empty slot to configure LAN Destinations.

Select the LAN Channel: To select the LAN Channel number.

LAN Channel: Displays LAN Channel Number for the selected slot (read-only).

LAN Destination: Displays ID for setting Destination Selector of Alert Policy (read-only).

Destination Type: Destination type can be either an SNMP Trap or an E-mail alert. For E-mail alerts, the four fields - SNMP Destination Address, BMC User Name, Email subject and Email message needs to be filled. The SMTP server information also has to be added - under [Settings ->SMTP Settings](#). For SNMP Trap, only the SNMP Destination Address has to be filled.

SNMP Destination Address: If Destination type is SNMP Trap, then enter the IP address of the system that will receive the alert. Destination address will support the following:

- IPv4 address format.
- IPv6 address format.

BMC User Name: If Destination type is Email Alert, then choose the user to whom the email alert has to be sent. Email address for the user has to be configured under [Settings->Users Management](#).

Email Subject & Email Message: These fields must be configured if email alert is chosen as destination type. An email will be sent to the configured email address of the user in case of any severity events with a subject specified in subject field and will contain the message field's content as the email body. These fields are not applicable for 'AMI-Format' email users.



NOTE

User should be configured under *Settings* → *Users Management*

Save: To add a new entry to the device. Alternatively, double click on a free slot.

Delete: To delete the selected configured LAN Destination.

Procedure

1. In the LAN Destinations section, choose the number of slots to be configured. This should be the same number of slot that you have selected in the Alert Policies - Destination Selector field. That is if you have chosen the Destination Selector as 4 in the Alert Policies page of Alert Policies tab, then you have to configure the 4th slot of LAN Destination page.
2. Select the slot and click on the empty slot. This opens the **LAN Destination entry**.

Add LAN Destination entry Page

3. In the LAN Channel Number field, the LAN Channel Number for the selected slot is displayed and this is a read only field.
4. In the LAN Destination field, the destination for the newly configured entry is displayed and this is a read only field.
5. In the Destination Type field, select the one of the types.
6. In the SNMP Destination Address field, enter the destination address.



NOTE

If Destination type is E-mail Alert, then give the e-mail address that will receive the e-mail.

7. If the destination type is Email alert, select the BMC User Name from the list of users.



NOTE

E-mail address should be configured under Settings → User Management.

8. In the Email Subject field, enter the subject.
9. In the Email Message field, enter the message.
10. Click Save to save the new LAN destination and return to LAN destination list.
11. Click Delete to delete a configuration.
12. Click Message icon (✉) to send sample alert to configured destination.




NOTE

Test alert can sent only with enabled SMTP configuration. SMTP support can be enabled under Settings → SMTP Settings.

4.2.12.5 Services

This page displays the basic information about services running in the BMC. Only Administrator can modify the service.

To open Services page, click [Settings](#) → [Services](#) from the menu bar. A sample screenshot of Services Page is shown below.



Service	Status	Interfaces	Secure Port	Timeout	Maximum Sessions
web	Active	eth0	443	1800	20
ssh	Active	NA	22	600	5
solssh	Inactive	NA	N/A	60	N/A

The fields of Services Page are explained below.

Services: Displays service name of the selected slot (read-only).

Status: Displays the current status of the service, either active or inactive state.

Interfaces: It shows the interface in which service is running.

Secure Port: Used to configure secure port number for the service.

- Web default port is 443
- SSH default port is 22



NOTE

Telnet service and SOLSSH will not support secure port. Port value ranges from 1 to 65535.

Timeout: Displays the session timeout value of the service. For web, SSH and telnet service, user can configure the session timeout value.



NOTE

- Web timeout value ranges from 300 to 1800 seconds.
- SSH and Telnet timeout value ranges from 60 to 1800 seconds.
- SSH and Telnet timeout value ranges from 60 to 1800 seconds.
- SSH and telnet service will be using the same timeout value. If you configure SSH timeout value, it will be applied to telnet service also and vice versa.

Maximum Sessions: Displays the maximum number of allowed sessions for the service.


Active Sessions: To view the current active sessions for the service.

To view the Active Sessions:**NOTE**

All active sessions in the BMC will be terminated if the BMC is rebooted.

Procedure:

1. Click View Icon () to view the details about the active sessions for the service.
2. This opens the **Active Session** screen (for example - Service Sessions) as shown in the screenshot below.



Session ID	Session Type	User ID	User Name	Client IP	Privilege
5	Web HTTPS	2	admin	192.168.22.64	Administrator

Service Sessions

3. **Session Type:** Displays the type of the active sessions.
4. **User:** Displays the name of the user.
5. **Client IP:** Displays the IP addresses that are already configured for the active sessions.
6. **Privilege:** Displays the access privilege of the user.
7. Select a slot and click **Terminate** icon () to terminate the particular session of the service.

To modify the existing services:**Procedure:**

1. Select a slot and click **Edit** icon () to modify the configuration of the service.

**NOTE**

Whenever the configuration is modified, the service will be restarted automatically. User has to close the existing opened session for the service if needed.

2. This opens the **Service Configuration** screen as shown in the screenshot below.

3. **Service Name** is a read only field.
4. Activate the Current State by enabling the **Active** check box.

**NOTE**

Interfaces, Nonsecure port, Secure port, Time out and Maximum Sessions will not be active unless the current state is active.

5. Choose any one of the available interfaces from the **Interface Name** drop-down list.
6. Enter the Secure Port Number in the **Secure Port** field.
7. Enter the timeout value in the **Timeout** field.

**NOTE**

The values in the **Maximum Sessions** field cannot be modified.

8. Click **Save** to save the entered changes else click **Cancel** to exit.

**NOTE**

Make sure that the SOLSSH service idle timeout should not be greater than the SSH idle timeout.

4.2.12.6 SMTP Settings

Simple Mail Transfer Protocol (SMTP) is an Internet standard for electronic mail (e-mail) transmission across Internet Protocol (IP) networks.

To open SMTP Settings page, click [Settings > SMTP Settings](#) from the menu bar. A sample screenshot of SMTP Settings Page is shown below.

SMTP Settings Page

The fields of SMTP Settings Page are explained below.

LAN Interface: Displays the list of LAN channels available

Sender Email ID: A valid 'Sender Address' to indicate the BMC, whenever e-mail is sent.

Primary Server Name: The 'Machine Name' of the BMC, from where the e-mail is sent.



NOTE

- Machine Name is a string of maximum 15 alpha-numeric characters.
- Space, special characters are not allowed.

Primary SMTP Support: To enable/disable SMTP support for the BMC.

Primary SMTP Port: To specify the SMTP Normal Port.

Primary Secure SMTP Port: To specify the SMTP Secure Port.



NOTE

- For Primary SMTP Port - Default Port is 25, and the Port value ranges from 1 to 65535.
- For Primary Secure SMTP Port - Default Port is 465, and the Port value ranges from 1 to 65535.

Primary Server IP: The IP address of the SMTP Server. It is a mandatory field.



NOTE

- IP Address made of 4 numbers separated by dots as in "xxx.xxx. xxx.xxx".
- Each Number ranges from 0 to 255.
- First Number must not be 0.
- Supports IPv4 Address format and IPv6 Address format.

Primary SMTP Authentication: To enable/disable SMTP Authentication.



NOTE

SMTP Server Authentication Types supported are:

- CRAM-MD5
- LOGIN
- PLAIN

If the SMTP server does not support any one of the above authentication types, the user will get an error message stating, Authentication type is not supported by SMTP Server.

Primary Username: Enter username to access SMTP Accounts.



NOTE

- User Name can be of length 4 to 64 alpha-numeric characters, dot(.), dash(-), and underline(_).
- It must start with an alphabet.
- Other Special Characters are not allowed.

Primary Password: Enter password for the SMTP User Account.



NOTE

- Password must be at least 4 characters long.
- White space is not allowed.
- This field will not allow more than 64 characters.

Primary SMTP STARTTLS Enable: To enable STARTTLS support for the SMTP Client.

Upload SMTP CA Certificate File: File that contains the certificate of the trusted CA certs.

- **Upload SMTP CA Certificate File:** File that contains the certificate of the trusted CA certs. CACERT key file should be of pem type.
- **Upload SMTP Certificate File:** Client certificate filename. CERT key file should be of pem type.
- **Upload SMTP Private Key:** Client private key filename. SMTP key file should be of pem type.



NOTE

To enable STARTTLS support, the respective SMTP support option should be enabled.

Primary SMTP SSL Enable: To enable SSL support for the SMTP Client.

Upload SMTP CA Certificate File: File that contains the certificate of the trusted CA certs.

- **Upload SMTP CA Certificate File:** File that contains the certificate of the trusted CA certs. CACERT key file should be of pem type.
- **Upload SMTP Certificate File:** Client certificate filename. CERT key file should be of pem type.
- **Upload SMTP Private Key:** Client private key filename. SMTP key file should be of pem type.



NOTE

To enable SSL support, the respective SMTP support option should be enabled.

Secondary SMTP Support: It lists the Secondary SMTP Server configuration. It is an optional field. If the Primary SMTP server is not working fine, then it tries with Secondary SMTP Server configuration.



NOTE

Options of Secondary SMTP Support are same as Primary SMTP Support.

Secondary SMTP STARTTLS Enable: To enable STARTTLS support for the SMTP Client.

- **Upload SMTP CA Certificate File:** File that contains the certificate of the trusted CA certs. CACERT key file should be of pem type.
- **Upload SMTP Certificate File:** Client certificate filename. CERT key file should be of pem type.
- **Upload SMTP Private Key:** Client private key filename. SMTP key file should be of pem type.

Save: To save the new SMTP server configuration.

Secondary SMTP SSL Enable: To enable SSL support for the SMTP Client.

- **Upload SMTP CA Certificate File:** File that contains the certificate of the trusted CA certs. CACERT key file should be of pem type.
- **Upload SMTP Certificate File:** Client certificate filename. CERT key file should be of pem type.
- **Upload SMTP Private Key:** Client private key filename. SMTP key file should be of pem type.

**NOTE**

To enable SSL support, the respective SMTP support option should be enabled.

Procedure

1. Select the LAN Interface from the drop-down list.
2. Enter the Sender Email ID in the specified field.
3. Check Primary SMTP Support option to enable SMTP support for the BMC.
4. Enter the Machine Name of the SMTP Server in the Primary Server Name.

**NOTE**

- Machine Name is a string of maximum 15 alpha-numeric characters.
- Space, special characters are not allowed.

5. Enter IP address of the SMTP Server in the Primary Server IP field. It is a mandatory field.
6. Enter the Primary SMTP Port in the specified field.
7. Enter the Primary Secure SMTP Port in the specified field.
8. Enable the check box Primary SMTP Authentication if you want to authenticate SMTP Server.
9. Enter your Primary User name and Primary Password in the respective fields.
10. Enable the check box Primary SMTP SSLTLS Enable to send data through secure Port.

**NOTE**

If this option is selected, STARTTLS option and Normal Port will be hidden.

11. Check the Secondary SMTP Support option to enable Secondary SMTP support for the BMC.
12. Enter the Secondary Server Name, Secondary Server IP, Secondary SMTP Port and Secure Port values in the respective fields.
13. Enable the check box SMTP Server Authentication if you want to authenticate SMTP Server.

**NOTE**

To enable SSL support, the respective SMTP support option should be enabled.

14. Enter your Secondary User name and Password in the respective fields.
15. Enable the check box Secondary SMTP SSLTLS to send data through secure Port.

**NOTE**

If this option is selected, STARTTLS option and Normal Port will be hidden.

16. Click Save to save the entered details.


4.2.12.7 System Firewall

The System Firewall page allows you to configure the firewall settings. The firewall rule can be set for an IP or range of IP Addresses or Port numbers. To view this page, you must at least be an operator. Only administrators can add or delete a firewall.

To open System Firewall page, click [Settings >System Firewall](#) from the menu bar.

4.2.12.7.1 General Firewall Settings

Click [General Firewall Settings](#) from the menu bar. A sample screenshot of General Firewall Settings page is shown below.




Firewall Settings

The fields of **Firewall Settings** tab are explained below.

Existing Firewall Settings

A blank page will be opened if you did not add anything in “Add Firewall settings”. If there is no Firewall Settings Exists, add a new Firewall settings by clicking link [Add Firewall Settings](#) page.

Click [General Firewall Settings > Existing Firewall Settings](#) icon. A sample screenshot of Existing Firewall Settings page is shown below.



Existing Firewall Settings

- **Block All:** The blocked incoming IP's and Port's.
- **Flush All:** To flush all the system firewall rules.
- Select **Timeout** to enable or disable firewall rules with timeout.
- **Time Out** - The respective firewall rule effect Start Time, End Date, Start Time, End Time will be displayed.
- **Delete:** To Delete the system firewall rules.

Add Firewall Settings

1. Click [General Firewall Settings > Add Firewall Settings](#). This opens the Add Firewall Settings page as shown below.

Add Firewall Settings

2. Select [Block All](#) to block all the incoming IP's and Port's.
3. Select [Flush All](#) to flush all the system firewall rules.
4. Select [Timeout](#) to enable or disable firewall rules with timeout.
5. Enter [Start Time](#) to start the respective firewall rule effect from this time.
6. Enter [End Time](#) to end the respective firewall rule effect from this time.



NOTE

The time should be in the dd-mm-yy:hh-mm format.

7. Click [Save](#) to save the changes made else click [Cancel](#) to go back to the previous screen.


4.2.12.7.2 IP Address Firewall Rules

To View Existing IP Rules or a range of IP Addresses

A blank page will be opened if you did not add anything in “Add IP Rule”. If there is no Add IP Rule Exists, add a new IP Rule by clicking link [Add IP Rule](#) page.

Procedure to Add IP Rule

1. Click [Settings > System Firewall > IP Address Firewall Rules > Existing IP Rules](#). A blank page will be opened if you did not add anything in “Add IP Rule”. If any rule is added, then the added rule will be listed in “Existing IP Rules” page.
2. Click the [IP Addresses](#) tab. A sample screenshot of **IP Addresses** tab is shown below.



System Firewall - Existing IP Rule

IP Single (or) Range Start: To show the configured Port Address or Range of Ports.

IP Range End: To show the configured Port Address or Range of Ports.

Enable Timeout: To enable/disable Timeout.

Start Date: The respective firewall rule effect will start from this date.

Start Time: The respective firewall rule effect will start from this time.

End Date: The respective firewall rule effect will end from this date.

End Time: The respective firewall rule effect will end from this time.

Rule: To indicate the current setting of the listed Port or Range of Port rules (Allow or Block) status.

Delete: To delete the selected slot.

Procedure To add an IP address or range of IP addresses

1. Click [Settings > System Firewall > IP Address Firewall Rules > Add New IP Rule](#) to add a new IP or range of IP address.

Add IP rule

2. In the **Add new rule for IP** page, Enter the IP address and a range of IP addresses in the **IP Single or IP Range Start** field.



NOTE

IP Address will support IPv4 Address format only:

- IPv4 Address made of 4 numbers separated by dots as in xxx.xxx.xxx.xxx.
- Each number ranges from 0 to 255.
- First number must not be 0.
- IPv6 Address made of 8 groups of 4 Hexadecimal digits separated by colon as in xxx x:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx.

3. Enter IP range end value in the **IP Range End** field.
4. Enable **Timeout** to enable firewall rules with timeout.
5. Enter **Start Date** to start the respective firewall rule effect from this date.
6. Enter **End Date** to end the respective firewall rule effect from this date.
7. Enter **Start Time** to start the respective firewall rule effect from this time.
8. Enter **End Time** to end the respective firewall rule effect from this time.

**NOTE**

The date and time should be in the YYYY/MM/DD and hh-mm format respectively.

9. Determine the rule to block or accept.
10. Click [Save](#) to save the changes made.

4.2.12.7.3 Port Firewall Rules

To view Existing Port Rules

1. Click [Settings > System Firewall > Port Firewall Rules > Existing Port Rules](#). A blank page will be opened if you did not add anything in “Add New port Rule”. If any rule is added, then the added rule will be listed in “Existing Port Rules” page
2. Click the [Existing Port Rules](#). A sample screenshot of Port tab is shown below.

The screenshot shows the 'Existing Port Rules' page in the BMC configuration interface. The page has a breadcrumb trail: Home > Settings > Firewall > Port Oriented Firewall Rules > Existing Port Rules > Existing Port Rules. The main content area displays a single rule configuration with the following details:

- Port Single (or) Range Start:** 4526
- Port Range End:** 5426
- Protocol:** TCP
- Network Type:** IPv4
- Enable Timeout:** ☒
- Start Date&Time:** Wed Sep 09 2020 14:17:00
- End Date&Time:** Wed Sep 09 2020 14:19:00
- Rule:** Allow

A red 'Delete' button is located at the bottom of the rule configuration box.

System Firewall - Existing Port Rules

The fields of System Firewall: **Existing Port Rules** page are explained below.

Port Single (or) Range Start : To configure the Port or Range of Port Addresses.

Port Range End : To configure the Port or Range of Port Addresses.

Protocol : This field specifies the protocols for the configured Port or Port Ranges.

Network Type : This field specifies the affected network type for the particular Port or Port Ranges.

Enable Timeout : To enable or disable firewall rules with timeout.

Start Date : The respective firewall rule effect will start from this time.

Start Time : The respective firewall rule will start from this time.

End Date : The respective firewall rule effect will end on this date.

End Time : The respective firewall rule will end at this time.

Rule : To indicate **Allow** or **Block** status.

Delete : To delete the entry to the firewall rules list.

Procedure

To Add Port/Range of ports

1. To add a new rage of Port address, click the [Add](#) button.

The screenshot shows the 'Add Port Rule' form in the BMC configuration interface. The form is located on the right side of the page, under the 'Port Oriented Firewall Rules' section. The form includes the following fields:

- Port Single (or) Range Start**: A text input field.
- Port Range End**: A text input field with the placeholder text 'optional'.
- Protocol**: A dropdown menu with 'TCP' selected.
- Network Type**: A dropdown menu with 'IPv4' selected.
- Enable Timeout**: A checkbox that is currently unchecked.
- Start Date**: A date input field with the placeholder text 'YYYY/MM/DD'.
- Start Time**: A time input field with a clock icon.
- End Date**: A date input field with the placeholder text 'YYYY/MM/DD'.
- End Time**: A time input field with a clock icon.

The interface also shows a breadcrumb trail at the top: Home > Settings > Firewall > Port Oriented Firewall Rules > Add Port Rule. The user is logged in as 'admin'.

Add Port rule

2. In the **Add new rule for Port** window, Enter the port number or a range of port numbers in the **Port Single (or) Range Start** field.

**NOTE**

Port value ranges from 1 to 65535.

3. Enter the end value in the **Port Range End** field.
4. Select the **Protocol** to be either TCP or UDP or Bot.
5. Select the **Network Type**. It may be IPv4 or IPv6 or Both.
6. Select **Timeout** to enable or disable firewall rules with timeout.
7. Enter **Start Time** to start the respective firewall rule effect from this time.
8. Enter **Start Date** to start the respective firewall rule effect from this date.
9. Enter **End Date** to end the respective firewall rule effect on this date.
10. Enter **End Time** to end the respective firewall rule effect at this time.

**NOTE**


The time should be in the YYYY/MM/DD:hh-mm format.

11. Select the **Rule** to determine the rule to **Block** or **Allow**.
1. 12. Click [Save](#) to save the changes made.

4.2.12.8 User Management

The User Management page allows you to view the current list of user slots for the server. You can add a new user and modify or delete the existing users.

To open User Management page, click [Settings > User Management](#) from the menu bar. A sample screenshot of User Management page is shown below.



Click **user icon** () and select any free slot to add a new user from the User Management main page.

Click **Delete icon** (x) on the top right corner to directly delete an item from the list.



NOTE

The Free slots are shown as “Disabled” in all columns for the slot.

The fields of User Management Page are explained below.

Channel: To choose a particular channel from the available channel list.

User ID: Displays the ID number of the user.



NOTE

The list contains a maximum of fifteen users only.

User Name: Displays the name of the user.

User Access: To enable or disable the access privilege of the user.

Network Privilege: Displays the network access privilege of the user.

SNMP Status: Displays if the SNMP status for the user is enabled or Disabled.

E-mail ID: Displays e-mail address of the user.

Add User: To add a new user.

Delete User: To delete an existing user.

Procedure to add a new User

1. To add a new user, select a free section and click on the empty section. This opens the Add User screen as shown in the screenshot below.

The screenshot displays the 'User Management Configuration' interface. At the top, there is a navigation bar with a hamburger menu, notification icons, language selection ('US - English'), 'Sync' and 'Refresh' buttons, and a user profile ('admin'). Below the navigation bar is a breadcrumb trail: 'Home > Settings > User Management > User Management Configuration'. The main content area contains a form for adding a new user. The form has a green question mark icon in the top right corner. The fields are as follows:

- Username:** A text input field.
- Password Size:** A dropdown menu currently set to '16 bytes'.
- Password:** A text input field.
- Confirm Password:** A text input field.
- Enable User Access:** A checkbox.
- Enable Channel Access:** A section with three checkboxes: 'Channel 1', 'Channel 2', and 'Channel 8'.
- Privilege(Channel 1):** A dropdown menu currently set to 'User'.
- Privilege(Channel 2):** A dropdown menu currently set to 'User'.
- Privilege(Channel 8):** A dropdown menu currently set to 'User'.
- KVM Access:** A checkbox.

User Management Configuration

2. Enter the name of the user in the **User Name** field.



NOTE

- User Name is a string of 1 to 16 alpha-numeric characters.
- It must start with an alphabetical character.
- It is case-sensitive.
- Special characters '-'(hyphen), '_'(underscore), '@'(at sign) are allowed.
- For 20 Bytes password, LAN session will not be established.

3. Set **Password Size** for the new password.

4. In the **Password** and **Confirm Password** fields, enter and confirm your new password.



NOTE

- Password should be the combination of alphabets, numbers, symbol and upper case characters.
- White space is not allowed.
- This field will not allow more than 16/20 characters based on Password size field value.
- This field will not allow the below mentioned characters.
- The password should be a string, if you try to set password using "ipmitool user set password".

Hex	Char	Hex	Char
00	NUL '\0'	11	DC1 (device control 1)
01	SOH (start of heading)	12	DC2 (device control 2)
02	STX (start of text)	13	DC3 (device control 3)
03	ETX (end of text)	14	DC4 (device control 4)
04	EOT (end of transmission)	15	NAK (negative ack.)
05	ENQ (enquiry)	16	SYN (synchronous idle)
06	ACK (acknowledge)	17	ETB (end of trans. blk)
07	BEL '\a' (bell)	18	CAN (cancel)
08	BS '\b' (backspace)	19	EM (end of medium)
09	HT '\t' (horizontal tab)	1A	SUB (substitute)
0A	LF '\n' (new line)	1B	ESC (escape)
0B	VT '\v' (vertical tab)	1C	FS (file separator)
0C	FF '\f' (form feed)	1D	GS (group separator)
0D	CR '\r' (carriage ret)	1E	RS (record separator)
0E	SO (shift out)	1F	US (unit separator)
0F	SI (shift in)	20	SPACE
10	DLE (data link escape)	7F	DEL

5. In **Enable User Access**, select this option to enable the network access for the appropriate user.

**NOTE**

- Enabling Channel User Access will intern assign the IPMI messaging privilege to the specific Channel user.
- It is recommended that the IPMI messaging option should be enabled for the user to enable the User Access option, while creating User through IPMI.

6. In **Enable Channel Access** field, select the channel/channels to enable the network access for the appropriate channels.
7. In the **Privilege** field, select the privilege assigned to the user which could be Administrator, Operator, User, OEM or None. By default, the channel privileges will be displayed based on the channel availability.
8. Check the **SNMP Access** check box to enable SNMP access for the user.

**NOTE**

Password field is mandatory, if SNMP Status is enabled.

9. Choose the SNMP Access level option for user from the **SNMP Access level** (SHA or MD5) drop-down list. Either it can be Read Only or Read Write.
10. Choose the **SNMP Authentication Protocol** (SHA256, SHA384 and SHA512) to use for SNMP settings from the drop down list.

**NOTE**

Password field is mandatory, if Authentication protocol is changed. Currently only SHA256, SHA384 and SHA512 is supported. SHA and MD5 protocols are deprecated and can be used only if previously configured and preserved user has this protocol enabled.

11. Choose the **Encryption algorithm** to use for SNMP settings from the **SNMP Privacy protocol** (AES or DES) drop-down list.
12. In the **Email ID** field, enter the email ID of the user. If the user forgets the password, the new password will be mailed to the configured email address.
- **Email Format:** Two types of formats are available:
 - **AMI-Format:** The subject of this mail format is 'Alert from (your Host name)'. The mail content shows sensor information, ex: Sensor type and Description.
 - **Fixed-Subject Format:** This format displays the message according to user's setting. You must set the subject and message for email alert.

**NOTE**

SMTP Server must be configured to send emails.

13. In the Upload SSH Key field, click Browse and select the SSH key file.



NOTE

SSH key file should be of pub type.

14. Click [Save](#) to save the new user and return to the users list.

To Modify User

1. To modify the existing user, click on the active user tab. This opens a User screen as shown in the screenshot below.

The screenshot displays the 'User Management Configuration' interface. It includes a sidebar with navigation links: Home, Settings, User Management, and User Management Configuration. The main content area contains the following fields and options:

- Username:** admin
- Logged-In Password:** (empty field)
- Change Password:** ☐
- Password Size:** 32 bytes (dropdown menu)
- Password:** (empty field)
- Confirm Password:** (empty field)
- Enable User Access:** ☒
- Enable Channel Access:**
 - ☒ Channel 1
 - ☒ Channel 2
 - ☒ Channel 8
- Privilege(Channel 1):** Administrator (dropdown menu)
- Privilege(Channel 2):** Administrator (dropdown menu)
- Privilege(Channel 8):** Administrator (dropdown menu)
- SNMP Access:** ☐

2. Check **Change Password**, if you wish to change the existing Password.

3. Follow the steps (3 to 15) of **Procedure to add a new User**.

4. Click [Save](#) to save the changes and return to the users list.

5. Click [Delete](#) to delete the user.



NOTE

There is a list of reserved users which cannot be added / modified as BMC users.


Important:

Reserved Users: There are certain reserved users which cannot be added as BMC Users. The list of reserved users are given below,

- sysadmin
- daemon
- sshd
- ntp
- root

4.2.12.9 Power Restore Policy

To open Power Restore Policy page, click [Settings > Power Restore Policy](#) from the menu bar. A sample screenshot of Power Restore Policy page is shown below.



Power Restore Policy

After an unexpected power failure, the state of the system power supply when the power supply is restored.

Always-off: Keep power off


Previous: Restore to the previous state

Always-on: Keep power on

4.2.12.10 Zone Configurations

Remove the SAS cable (SFF-8644) between the HBA/RAID card and the JBOD-4U60 before configuring T10 zoning. After configuring T10 zoning, please power cycle the JBOD-4U60 and then insert the SAS cable back (SFF-8644).

To open Zone Configurations page, click [Settings > Zone Configurations](#) from the menu bar. A sample screenshot of Zone Configurations page is shown below.



Zone Configuration page

In the BMC Web UI, we only provide three predefined T10 zoning settings: 1 (disabled), 2 and 4. The PHYs of the SAS expanders for the wideport (Hub) and disks (Edge) will be separated into different zoning groups if the zoning is enabled.

The predefined zoning groups for different settings are as followed:

Zone Count 1: (Disable Zoning)

Hub:

Zoning Group	1
Wideport	1,2,3,4

Edge:

Zoning Group	1
Disk Slot	1~60

Zone Count 2:

Hub:

Zoning Group	1	2
Wideport	1,2	3,4

Edge:

Zoning Group	1	2
Disk Slot	1~30	31~60

Zone Count 4:

Hub:

Zoning Group	1	2	3	4
Wideport	1	2	3	4

Edge:

Zoning Group	1	2	3	4
Disk Slot	1~15	16~30	31~45	46~60

4.2.13 Remote Control

To open the Settings page, click [Remote Control](#) from the menu bar.

The Remote Control page consists of the following options. A sample screenshot is displayed below.




Remote Control page

4.2.13.1 Launch Serial Over LAN

Serial Over LAN (SOL) is a mechanism that enables the input and output of the serial port for a managed system to be redirected over IP; In this feature, Serial data is transmitted to HTML5 Web UI through websocket.

To activate SOL function, follow the below procedures:

1. Click Activate to activate SOL. A blank screen will appear as shown below.




NOTE

Remote Control only support HUB EXP in J4060-04-35X

4.2.14 Chassis Identify

To open the Chassis Identify page, click [Chassis Identify](#) from the menu bar. A sample screenshot of the Chassis Identify page is shown below.



Chassis Identify page


The various options of Chassis Identify LED Control are given below.

Chassis Identify Off: Turn off the chassis identify LED.

Chassis Identify On: Turn on the chassis identify LED.

4.2.15 HDD Management

To open HDD Management, click [HDD Management](#) from the menu bar. This page allows you to view and control the hard disk drives. A sample screenshot of the hdd management page is shown below.



HDD Management page

Each hard disk drive will display a different color representing a different state including normal, abnormal and absence, etc.

The various options of HDD Power Control are given below.

Power on: To power on the hard disk driver.

Power off: To power off the hard disk driver.




NOTE

The function can only work when the system power is on

4.2.16 Power Control

This page allows you to view and control the power of your server.

To open Power Control, click [Power Control](#) from the menu bar. A sample screenshot of Power Control is shown below.



Power Control page

The various options of Power Control are given below.

Power Off: To immediately power off the server.

Power On: To power on the server.

Power Cycle: This option will first power off, and then reboot the system (cold boot).

Procedure

Select an action and click [Perform Action](#) to proceed with the selected action.



NOTE


During Execution you will be asked to confirm your choice. Upon confirmation, you will be informed about the status after few minutes.

4.2.17 Maintenance Group

To open the Maintenance page, click [Maintenance](#) from the menu bar. This group of pages allows you to do maintenance tasks on the device. The menu contains the following items:

- Backup Configuration
- Firmware Image Location
- BMC Firmware Information
- BMC Firmware Update
- Preserve Configuration
- Restore Configuration
- Restore Factory Defaults
- CPLD Firmware Update
- BMC Reset

A sample screenshot of Maintenance page is displayed below.




Maintenance page

4.2.17.1 Backup Configuration

This page allows you to select the specific configuration items to be backup in case of “Backup Configuration”.

To open Backup Configuration page, click [Maintenance > Backup Configuration](#) from the menu bar. A sample screenshot of Backup Configuration page is shown below.



Backup Configuration

The various fields of Backup Configuration page are given below.

Check All: To select all the configuration list.

Download Config: To download and save the configuration files backup from BMC to client system.




NOTE

During backup, because of security concern, the mechanism parses sensitive data to filter it out and not backup sensitive files. User has to set password again after restoring configuration by using default user in case of login failure.

4.2.17.2 Backup Configuration

This page allows you to select the specific configuration items to be backup in case of “Backup Configuration”.

To open Backup Configuration page, click [Maintenance > Backup Configuration](#) from the menu bar. A sample screenshot of Backup Configuration page is shown below.



Backup Configuration page

The various fields of Backup Configuration page are given below.

Check All: To select all the configuration list.

Download Config: To download and save the configuration files backup from BMC to client system.



NOTE

During backup, because of security concern, the mechanism parses sensitive data to filter it out and not backup sensitive files. User has to set password again after restoring configuration by using default user in case of login failure.

Procedure for Backup Configuration

1. Click [Check All](#) to back up all the configuration items or check the configuration that needs to be back up. The Backup Configuration page will appear as shown in the above screenshot.



NOTE

Network configurations are inter-related to IPMI, and hence by default IPMI configurations will be selected automatically when you select “Network and Services” to be backed up.

2. Click [Download Config](#) to save the backup file to the client system.

3. Click OK to perform the backup action. The Backup file will be saved in the client system.
4. Click Cancel to cancel the backup process.

**NOTE**

If select sd/emmc for backup conf space, has to create /confbkup folder in sd/emmc parti-tion before backup.

TFTP server configuration

The TFTP server configuration is used for exporting the backup file.

**NOTE**

Ensure that no other TFTP servers are enabled, if so remove all other servers with all con- figuration files. Login as “super” user means “root” user.

Procedure to make the default tftp server

1. Install the application which are needed.

```
apt-get install xinetd tftp tftpd
```

2. Edit the configuration file for TFTP.

A. Edit tftp

```
vi /etc/xinetd.d/tftp
```

Edit the file as below:

```
service tftp
{
  protocol = udp
  port = 69
  socket_type = dgram
  wait = yes
  user = nobody
  server = /usr/sbin/in.tftpd
  server_args = <DIR to which the file to be access>
  disable = no
}
#EOF
#example:server_args = /tftpboot
```

**NOTE**

No arguments to be passed to the server_args other than directory.

B. Edit xinetd.conf

```
vi /etc/xinetd.conf
```

Add to the file:

```
defaults
```

```
{
```

Please note that you need a log_type line to use log_on_success and log_on_failure.

The default is the following :

```
# log_type = SYSLOG daemon info
}
includedir /etc/xinetd.d
```

3. Restart the server.

```
/etc/init.d/xinetd restart
```

4. Give permission to the file to access by all.

```
mkdir <DIR>
```

```
chmod -R 777 <DIR>
```

```
chown -R nobody <DIR>
```

For Example:

```
mkdir /tftpboot
```

```
chmod -R 777 /tftpboot
```

```
chown -R nobody /tftpboot
```

5. To receive the file you have to touch the file and give permission to access by all users

```
touch <DIR>/conf.bak
```

```
chmod 777 <DIR>/conf.bak
```

6. Even after all this step has been done and still facing error of timeout:

A. Check with /etc/xinetd.d/tftp file and uncomment the EOF (Remove the '#' before the EOF alone).

B. Restart the server.

4.2.17.3 Firmware Image Location

This page is used to configure firmware image into the BMC.

To open **Firmware Image Location**, click [Maintenance > Firmware Image Location](#) from the menu bar. A sample screenshot of **Firmware Image Location** page is shown below.

Firmware Image Location

The various options of Image Transfer Protocol are given below.

Image Location Type : Type of location to transfer the firmware image into the BMC either **Web Upload during Flash** or **TFTP Server**.

TFTP/SFTP Server Address: Address of the server where the firmware image is stored.



NOTE

The Server supports both IPv4 and IPv6 addresses

- IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx".
- Each number ranges from 0 to 255.
- First number must not be 0.
- IPv6 Address made of 8 groups of 4 Hexadecimal digits separated by colon as in "xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx".
- Hexadecimal digits are expressed as lower-case letters.

TFTP/SFTP Image Name: Full Source path with filename of the firmware image is stored on TFTP/SFTP Server.

TFTP/SFTP Retry Count: Number of times to be retried in case a transfer failure occurs. Retry count ranges from 0 to 255.

Save: To save the configured settings.


Procedure

1. Select the **Image Location Type** (Web Upload during flash/ TFTP Server/ SFTP Server).
2. If the protocol selected is TFTP/SFTP, enter the IP address of the server in the **Server Address** field.
3. If the protocol selected is TFTP/SFTP, enter the **Image Name** in the given field.
4. If the protocol selected is TFTP/SFTP, enter the **Retry Count** value.
5. If the protocol selected is SFTP, enter the **Username** and **Password** value.
6. Click **Save** to save the changes.

4.2.17.4 BMC Firmware Information

This page is used to configure the Firmware Information settings.

To open System Administrator page, click [Maintenance > BMC Firmware Information](#) from the menu bar. A sample screenshot of BMC Firmware Information page is shown below.



BMC Firmware Information page

The various fields of BMC Firmware Information page are given below.

Active Image ID: Describes the Active Image ID of the active BMC image.

Build Date: Describes the Build Date of the active BMC image.

Build Time: Describes the Build Time of the active BMC image.

Firmware version: Describes the Firmware version of the active BMC image.

Firmware name: Describes the Firmware name of the active BMC image.

4.2.17.5 Preserve Configuration

This page allows the user to configure the preserve configuration items, which will be used by the Restore factory defaults to preserve the existing configuration without overwriting with defaults/ Firmware Upgrade configuration.

To open Preserve Configuration page, click [Maintenance > Preserve Configuration](#) from the menu bar. A sample screenshot of Preserve Configuration page is shown below.

Preserve Configuration

Home > Maintenance > Preserve Configuration

Click here to go to [Firmware Update](#) or [Restore Factory Defaults](#)

☐ Check All

☐ SDR

☐ FRU

☐ SEL

☐ IPMI

☐ Network

☐ NTP

☐ SNMP

☐ SSH

☐ Authentication

☐ Syslog

☐ Web

☐ Redfish

Preserve Configuration page

The various fields of Preserve Configuration are as follows.

Click here to go to Firmware Update or Restore Configuration: This link will redirect to the Firmware Update or Restore Configuration page which needs to be preserved.

Check All: To check the entire configuration list.

Save: To save any changes made.



NOTE

This configuration is used by Restore Factory Defaults process. You can navigate to the Firmware Update Page and Restore Factory Defaults by clicking the respective links.

Files Preserved**SDR**

Following files will be preserved.

SDR.dat: This file contains the sensor data record information that is used in IPMI.

Dependency Configurations – NIL

FRU

Following files will be preserved.

FRU.bin: This file contains the logical field replaceable unit data that are used by IPMI.

Dependency Configurations - SDR

SEL

Following files will be preserved when Delete SEL reclaim space is disabled.

SEL.dat: This file contains the system event logs that are being logged by the IPMI.

Following files will be preserved when Delete SEL reclaim space is enabled.

Selreclaiminfo.ini – The file contains the SEL repository information.

SEL folder – This folder contains the multiple files of event logs.

Dependency Configurations – IPMI

IPMI

Select “IPMI” will automatically select another option “Network” and it’s vice versa. The following files are preserved in IPMI configuration.

IPMI.conf: This file contains the IPMI configurations such as SEL rep size, SDR rep size, interface specific, enable/disable, Primary/Secondary, IPMB Bus number etc.

Dcmi.conf: This file contains the DCMI1.5 specification parameters such as DHCP Timing1, DHCP Timing2, DHCP Timing3. The files are preserved only when DCMI1.5 feature is enabled in the MDS project configuration.

pwdEncKey: This file contains the keys that are used to decrypt the passwords. When the user password option is enabled in the MDS project configuration, this file will be preserved.

Dependency Configurations – Network

Network

To save network settings related with IPMI (LAN IP or DHCP configuration), selecting “IPMI” will automatically select the another option “Network” and it’s vice versa. After restore configuration, the Network Configuration will be preserved successfully. Following files will also be preserved.

dhcp.conf: This file is to configure the host name in the FQDN format.

dns.conf: This file is used to configure the DNS registration method and DNS server for the particular interface.

hostname: This file is used to store the Hostname of the BMC.

hostname.conf: This file is used to configure the host name creation method Manual/ Automatic for the BMC.

Vlaninterfaces: This file helps to enable the vlan interface for the particular LAN interface

vlansetting.conf: This file is to store the vlan ID and Vlan priority for the particular VLAN interface entry.

bond.conf: This file is to enable the bond interface for the specified LAN interfaces.

Interfaces: This file is to configure the IP/IPV6 addresses for the LAN interface using static/ DHCP method.

activeslave.conf: This file is to configure the active interface for the specified bond interface. This file depends on bond.conf.

hosts: This file is used to store the host name to map the IP address.

hosts.allow: This file contains the list of hosts that has permission to access the system.

hosts.deny: This file contains the list of host that does not allow accessing the system.

resolv.conf: This file is used to store the name server and domain name for hostname registration.

dhcp6c-script: This file is used to configure the domain name, DNS server IPv6 address and NTP address.

dhcp6c.conf: This file is to configure the IPv6 parameters for the DHCPv6 clients.

ncsicfg.conf: This file is to configure the NCSI related configurations.

nsupdate.conf: This file is to configure the channel ID, package ID for the NCSI interface.

phycfg.conf: This file is to configure the link speed, duplex and MTU value for the specified interface.

dhcp.preip_4: This file is to store the pre IPv4 address. This file will be created at runtime.

ncml.conf: This file contains service configuration details.

Dependency Configurations - IPMI

NTP

Following files will be preserved.

Ntp.conf: This file contains the NTP dameon protocol configuration parameters such as synchronization sources, nodes and other related information.

Ntp.stat: This file contains the auto or manual network type protocols.

adjtime: This file contains the time to synchronize the system clock.

Localtime: This file is the system link to the file local time or to the correct time zone in the system timezone directly.

Dependency Configurations - IPMI

SNMP

Following files will be preserved.

snmp_users.conf: This file contains the SNMP user configurations such as user name and password encryption mechanism for the specific users.

Snmpcfg.conf: This file contains the SNMP users privilege levels such as ro user and rw user.

Dependency Configurations - NIL

SSH

Following files will be preserved.

snmp_users.conf: This file contains the keyword argument pairs of configurations such as Address family, Accept Env, Allow, users, authorized key files etc.

ssh_host_dsa_key , ssh_host_rsa_key: These files contain the private parts of the host keys.

ssh_host_dsa_key.pub, ssh_host_rsa_key.pub: These files contain the public parts of the host keys.

Dependency Configurations - NIL

Authentication

Following files will be preserved.

activedir.conf: This file contains the configurations such as sslenable, timeout, racdomain, adtype, adfilterdc1, adfilterdc2, adfilterdc3, username, password, and rolegroup information such as name domain and privileges.

openLdapGroup.conf: This file contains the oprnm ldap role group information such as name domain and privilege.

nsswitch.conf: This file contains the sources to obtain the name service information in the range of categories and in what order.

pam_withunix: This file contains the PAM Order of modules such as IPMI, LDAP, RADIUS and UNIX.

pam_wounix: This contains the PAM Order of modules such as IPMI, LDAP and RADIUS.

group: This file contains the Linux group. It stores the group information or defines the user group information in Linux.

passwd: This file contains the user login information for the Linux system.

shadow: This file contains the encrypted password information for the clients.

ldap.conf: This file contains the ldap server configuration details such as binddn, binpw, pam_password, nss_reconnect_tries, port, port secondary, host, host secondary.

radius.conf: This file contains the radius server IP address, port number, secret, timeout, privilege etc.

Dependency Configurations – NIL

Syslog

The following files will be preserved.

syslog.conf

rotate.conf

rsyslog.conf

These files contain the system log configuration details to preserve different event categories such as alert, critical, error notification etc.

Dependency Configurations – NIL

Web

The following files will be preserved.

updatefirmware.conf: This file contains the firmware image location details to update firmware configuration.

Dependency Configurations – NIL

Redfish

Following files will be preserved.

redis-dump.rdb.gz: This gzip file contains compressed redis db data.

RedisdbChecksum: This is the checksum value of redis-dump.rdb.gz file..

redfish: This folder contains the multiple files of Redfish.

Dependency Configurations – IPMI


Procedure

1. Click [Firmware Update or Restore Configuration](#) link to view Firmware Update or Restore Configuration page accordingly.
2. Select the required Preserve Configuration items by either choosing the items individually by selecting the appropriate check boxes or by selecting all or none using **Check All**.
3. Click [Save](#) to save the changes.

4.2.17.6 Restore Configuration

This page allows you to restore the configuration files from the client system to the BMC.

To open Restore Configuration page, click [Maintenance > Restore Configuration](#) from the menu bar. A sample screenshot of Restore Configuration page is shown below.



Restore Configuration


The various fields Restore Configuration page are given below.

Config File : This option is used to select the file which was back up earlier.

Upload : To upload the backup file to restore the backup files.

Procedure for Restore Configuration

1. Click [Browse](#) to select the configuration file that needs to be backup and used to Restore the configuration, when needed.
2. Click [Upload](#) to restore the backup files. The Restore Configuration page will appear as shown below.



3. Click [OK](#) to upload the new configuration file and restore.

4.2.17.7 Restore Factory Defaults


This option is used to restore the factory defaults of the device firmware. This section lists the configuration items that will be preserved during restore factory default configuration.



Warning

Please note that after entering restore factory widgets, other web pages and services will not work. All open widgets will be closed automatically. The device will reset and reboot within few minutes.

To open Restore Factory Defaults page, click [Maintenance > Restore Factory Defaults](#) from the menu bar. A sample screenshot of Restore Factory Defaults Page is shown below.



Restore Factory Defaults

Procedure

1. Click [Preserve Configuration](#) to redirect to **Preserve Configuration** page, which is used to preserve the particular configuration not to be overwritten by the default configuration.
2. Click [Restore Factory Defaults](#) to restore the factory defaults of the device firmware.



NOTE

When Restore Factory Defaults action is performed, there might be some log events present after performing restore operation. Those events might be newly generated which can be verified using its timestamp.

4.2.17.8 CPLD Firmware Update

This page is used to update CPLD firmware.

To open BMC Rest page, click [Maintenance](#) > [CPLD Firmware Update](#) from the menu bar. A sample screenshot of CPLD Firmware Update page is shown below.

CPLD Firmware Update

Home > Maintenance > CPLD Firmware Update

Note:
Following are the Firmware update methods and components supported in this page.

- CPLD Firmware update.

Select Firmware Image

Start firmware update

WARNING:Please note that after entering the update mode, the widgets, other web pages and services will not work. All the open widgets will be automatically closed.

CPLD Firmware Update page

Procedure for CPLD Firmware Update

1. Click Choose File to select firmware image.
2. Click Start firmware update to load the Firmware Update information

CPLD Firmware Update

Home > Maintenance > CPLD Firmware Update

Note:
Following are the Firmware update methods and components supported in this page.

- CPLD Firmware update.

Select Firmware Image

4U60_4U90_cpld_v0.0.10_20240105.hpm

Start firmware update

Preparing to flash...

☒ Update All

List of Components

#	Component Name	Existing Version	Uploaded Version	Upgrade
1	CPLD	0.0.10	0.0.10	☒

Proceed


WARNING:Please note that after entering the update mode, the widgets, other web pages and services will not work. All the open widgets will be automatically closed.

3. Check the correctness of the firmware version and click Proceed to update CPLD Firmware.

4.2.17.9 Reset BMC

This page is used to reset BMC firmware.

To open BMC Reset page, click [Maintenance > BMC Reset](#) from the menu bar. A sample screenshot of BMC Reset page is shown below.



BMC Reset page

The various options of Power Control are given below.


Self: activate BMC

Others: other BMC

Click **Reset** button to reset the selected BMC firmware.

4.2.18 Sign Out

To log out from , click the [admin](#) on the top right corner of the screen. A sample screenshot of admin option is shown below.



Sign out

Click [Sign Out](#) to perform log out. A Warning message will be prompted you to proceed further, click [OK](#) to log out or [Cancel](#) to retain the interface.

4.2.19 Utility & Tool

4.2.19.1 Flash Tools

The Flash Tools are command line utility programs used to upgrade the firmware using different medium like KCS, USB, and LAN. There are three tools, which are being used **YAFUFlash**.

4.2.19.1.1 YAFUFlash

Yet Another Firmware Upgrade Flash is a tool used for flashing the BMC. This utility is used for flashing in both Linux and Windows environment. There are three types of mediums used to flash the BMC. They are,

- Network
- USB ([Not supported in this platform](#))
- KCS ([Not supported in this platform](#))

All the three mediums are applicable for Windows and Linux environment. But only KCS medium can be used in DOS 1.2. environment. The medium can be selected as per your requirement.



NOTE

YAFU based firmware update using Signed Hashed image is only possible if enough RAM is available to upload the full firmware image before the update starts.

In YAFU firmware upgrade, only YAFU command set is allowed if **Enable IPMI Command handling during flashing** support is disabled in project configuration.

YAFU flashing process has the following timeout values

LAN interface: 3600 seconds

USB interface: 1800 seconds

KCS interface: 5400 seconds

If Secure Boot Support is enabled in the PRJ, YAFUFlash options for Section Based Flashing or Interactive mode will not be used. Hence any feature or options that rely on Section Based Flashing or Interactive mode cannot be used when Secure Boot Support is enabled.

4.2.19.1.2 Installation in Windows

1. Open the command prompt in administrator mode and enter YafuFlash\Windows path.
2. This contains two files, Yafuflash.exe and LIBIPMI.dll.
3. Format: Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE], where Perform BMC Flash Update
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List outs a few examples of the tool

[OPTIONS]

-info	Displays information about existing FW and new FW.
-msi,img-section-info	Displays information about current FW Sections.
-mi,img-info	Displays information about current FW Versions.
-fb, -force-boot	Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.
-pc, -preserve-config	Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.
-q, -quite	Use the option to show the minimum flash progress details.
-i	Option to interactive upgrade (Upgrade only required modules)**
-f, -full	Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade
-ipc, -ignore-platform-check	If this image is for a different platform, this option skips user interaction and continues update process.
-idi,ignore-diff-image	If this image differs from the currently programmed image, this option skips user interaction and continues update process.
-isi, -ignore-same-image	If this image is same as the currently programmed image, this option skips user interaction and continues update process.
-iml, -ignore-module-location	If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.
-ibv, -ignore-boot-version	If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.
-iri, -ignore -reselect-image	Option skips reselecting the active image.

-inc, -ignore-non-preserve-config	Option skips the restore to default factor setting if the image shares the same configuration area.
-mse, -img-select	Option to specify the Image to be updated 0 - Inactive Image 1 - Image 1 2 - Image 2 3 - Both Images
-rp, replace-publickey	Option to replace the Signed Image Key in Existing Firmware.
-vcf, -version-cmp-flash	Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.
-non-interactive	This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-sameimage', '-ignore- module-location' & '-ignoreboot-version' options.
-pXXX, -preserve-XXX	Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask to confirm that those configuration is to be preserved.
-ieo, -ignore-existing-overrides	Clears the existing overrides and preserves only the overrides given in command line if any.
-msp, split-img	Option to flash the split image.
-f -XXX, -flash-XXX	Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.
-sc, -skip-crc	Option to skip the CRC check
-sf, -skip-fmh	Option to skip the FMH check
-d	Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS <bit2> - CPLD <BIT4> - ME
-a, -activate	Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS <BIT2> - CPLD
-nr, -no-reboot	Option to skip the reboot. With online-flash support, if conf/extlog is not preserved, BMC will still reboot.
-bu, -block-upgrade	Option to Flash using Block by Block method
-netfn <NETFN>	Option to specify AMI OEM Net Function (default 0x32)

[MEDIUM]

-cd	Option to use USB Medium
-nw,-ip,-u,-p,-host, _p	Option to use Network Medium: '-ip' Option to enter IP, when using Network Medium '-host' Option to enter host name, when using Network Medium. '-u' Option to enter UserName, when using Network Medium. '-p' Option to enter Password, when using Network Medium. '_p' Option to enter Port Number.
-kcs	Option to use KCS medium.
Option to use KCS medium.	Option to use serial interface.
-term	Option to use serial command, e.g. /dev/ttyS0.
-baudrate	Option to use baudrate of the serial terminal, e.g. 115200.

[FW_IMAGE_FILE] Firmware image file name [rom.ima].

-pe,-preserve-extlog	Option to preserve extlog configuration during firmware flash.
----------------------	--

**NOTE**

'-preserve-config' and '-force-boot' option not be used in interactive upgrade.

Examples for Network Medium

Eg1:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of both existing firmware and new firmware.

Eg2:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware.

Eg3:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -preserve-config
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with preserve config params.

Eg5:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot  
-preserve-config
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg6:

```
./Yafuflash -nw -host spxbmc -force-boot -preserve-config rom.ima
```

Description: This command works with network medium using the host name spxbmc, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg7:

```
./Yafuflash -nw -ip 2000::2005 -force-boot rom.ima
```

Description: This command works with network medium using the ipv6 address 2000::2005, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg8:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -i
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima using interactive upgrade mode and user will be prompt to select the Number of modules and module names to upgrade.

Eg9:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg10:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of existing firmware Version.

Eg11:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey
```

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in firmware.

Eg12:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg13:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg14:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg15:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existingoverrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg16:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg17:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserveconfig
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg18:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 0 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg19:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 1 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg20:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 2 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg21:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 3 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg22:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -quite
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima with minimum progress details.

Eg23:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img boot.ima
```

Description: This command works with network medium to flash the boot split image.

Eg24:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img root.ima
```

Description: This command works with network medium to flash the root split image.

Eg25:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -flash-root -flash-conf
```

Description: This command works with network medium to flash root and conf section from rom. ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg26:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin boot.ima -split-img -flash-boot
```

Description: This command works with network medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg27:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with network medium to flash www and osimage from root. ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg28:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -preserve-extlog
```

Description: This command works with network medium to preserve extended log configuration.

Eg29:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -preserve-extlog
```

Description: This command works with network medium to preserve extended log configuration from split image.

Eg30:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 rom.ima
```

Description: This command works with network medium to flash the image on specific peripheral device.

Eg31:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 root.ima -split-img
```

Description: This command works with network medium to flash the split image on specific peripheral device.

Eg32:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin -bu root.ima.
```

Description: This command works with network medium to flash the image on specific peripheral device by block by block upgrade.

Eg33:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -netfn 0x36
```

Description: This command works with network medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

Examples for USB Medium

Power Save Mode should be disabled for Flashing with Yafu USB Interface.

Eg1:

```
./Yafuflash -cd rom.ima -info
```

Description: This command works with USB medium which displays the details of both Existing Firmware and new firmware.

Eg2:

```
./Yafuflash -cd rom.ima
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware.

Eg3:

```
./Yafuflash -cd rom.ima -force-boot
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -cd rom.ima -preserve-config
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with preserving config params.

Eg5:

```
./Yafuflash -cd rom.ima -force-boot -preserve-config
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade and preserving config params.

Eg6:

```
./Yafuflash -cd rom.ima -i
```

Description: This command works with USB medium, which start to flash the new rom. ima using interactive upgrade mode and user, will be prompt to select the number of modules and module names to upgrade.

Eg7:

```
./Yafuflash -cd -img-section-info
```

Description: This command works with USB medium which displays the details of Existing Firmware.

Eg8:

```
./Yafuflash -cd -img-info
```

Description: This command works with USB medium which displays the details of Existing Firmware Version.

Eg9:

```
./Yafuflash -cd public.pem -replace-publickey
```

Description: This command works with USB medium which replaces the public key in Existing Firmware.

Eg10:

```
./Yafuflash -cd rom.ima -preserve-sel -preserve-ipmi
```

Description: This command works with USB medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11:

```
./Yafuflash -cd rom.ima -preserve-sel -ignore-existing-overrides
```

Description: This command works with USB medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg12:

```
./Yafuflash -cd rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13:

```
./Yafuflash -cd rom.ima -ignore-non-preserve-config
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14:

```
./Yafuflash -cd -img-select 0 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15:

```
./Yafuflash -cd -img-select 1 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16:

```
./Yafuflash -cd -img-select 2 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17:

```
./Yafuflash -cd -img-select 3 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18:

```
./Yafuflash -cd rom.ima -quite
```

Description: This command works with USB medium, which start to flash the new rom.ima with minimum progress details.

Eg19:

```
./Yafuflash -cd -split-img boot.ima
```

Description: This command works with USB medium to flash the boot split image.

Eg20:

```
./Yafuflash -cd -split-img root.ima
```

Description: This command works with USB medium to flash the root split image.

Eg21:

```
./Yafuflash -cd rom.ima -flash-root -flash-conf
```

Description: This command works with USB medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg22:

```
./Yafuflash -cd boot.ima -split-img -flash-boot
```

Description: This command works with USB medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg23:

```
./Yafuflash -cd root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with USB medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg24:

```
./Yafuflash -cd rom.ima -preserve-extlog
```

Description: This command works with USB medium to preserve extended log configuration.

Eg25:

```
./Yafuflash -cd root.ima -split-img -preserve-extlog
```

Description: This command works with USB medium to preserve extended log configuration from split image.

Eg26:

```
./Yafuflash -cd root.ima -d 1 rom.ima
```

Description: This command works with USB medium to flash the image on specific peripheral device.

Eg27:

```
./Yafuflash -cd root.ima -d 1 root.ima -split-img
```

Description: This command works with USB medium to flash the split image on specific peripheral device.

Eg28:

```
./Yafuflash -cd rom.ima -netfn 0x36
```

Description: This command works with USB medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

Examples for KCS Medium

Eg1:

```
./Yafuflash -kcs rom.ima -info
```

Description: This command works with KCS medium which displays the details of both Existing Firmware and new firmware.

Eg2:

```
./Yafuflash -kcs rom.ima
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware.

Eg3:

```
./Yafuflash -kcs rom.ima -force-boot
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -kcs rom.ima -preserve-config
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with preserving config params.

Eg5:

```
./Yafuflash -kcs rom.ima -force-boot -preserve-config
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade and preserving config params.

Eg6:

```
./Yafuflash -kcs rom.ima -i
```

Description: This command works with KCS medium, which start to flash the new rom. ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7:

```
./Yafuflash -kcs -img-section-info
```

Description: This command works with KCS medium which displays the details of Existing Firmware.

Eg8:

```
./Yafuflash -kcs -img-info
```

Description: This command works with KCS medium which displays the details of Existing Firmware Version.

Eg9:

```
./Yafuflash -kcs public.pem -replace-publickey
```

Description: This command works with KCS medium which replaces the public key in Existing Firmware.

Eg10:

```
./Yafuflash -kcs rom.ima -preserve-sel -preserve-ipmi
```

Description: This command works with KCS medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11:

```
./Yafuflash -kcs rom.ima -preserve-sel -ignore-existing-overrides
```

Description: This command works with KCS medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg12:

```
./Yafuflash -kcs rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13:

```
./Yafuflash -kcs rom.ima -ignore-non-preserve-con
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14:

```
./Yafuflash -kcs -img-select 0 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15:

```
./Yafuflash -kcs -img-select 1 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16:

```
./Yafuflash -kcs -img-select 2 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17:

```
./Yafuflash -kcs -img-select 3 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18:

```
./Yafuflash -kcs rom.ima -quite
```

Description: This command works with KCS medium, which start to flash the new rom.ima with minimum progress details.

Eg19:

```
./Yafuflash -kcs -split-img boot.ima
```

Description: This command works with KCS medium to flash the boot split image.

Eg20:

```
./Yafuflash -kcs -split-img root.ima
```

Description: This command works with KCS medium to flash the root split image.

Eg21:

```
./Yafuflash -kcs rom.ima -flash-root -flash-conf
```

Description: This command works with KCS medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg22:

```
./Yafuflash -kcs boot.ima -split-img -flash-boot
```

Description: This command works with KCS medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg23:

```
./Yafuflash -kcs root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with KCS medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg24:

```
./Yafuflash -kcs rom.ima -preserve-extlog
```

Description: This command works with KCS medium to preserve extended log configuration.

Eg25:

```
./Yafuflash -kcs root.ima -split-img -preserve-extlog
```

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg26:

```
./Yafuflash -kcs root.ima -d 1 rom.ima
```

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg27:

```
./Yafuflash -kcs root.ima -d 1 root.ima -split-img
```

Description: This command works with KCS medium to flash the split image on specific peripheral device.

Eg28:

```
./Yafuflash -kcs rom.ima -netfn 0x36
```

Description: This command works with KCS medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

4.2.19.1.3 Installation in Linux

1. OpenSSL is pre-requisite for YafuFlash.
2. Open Terminal and go to YafuFlash/Linux path.
3. This contains Yafuflash tool.
4. Run ./Yafuflash in the terminal.
5. Format: Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE], where Perform BMC Flash Update
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List outs a few examples of the tool

[OPTIONS]

-info	Displays information about existing FW and new FW.
-msi,-img-section-info	Displays information about current FW Sections.
-mi,-img-info	Displays information about current FW Versions.
-fb, -force-boot	Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.
-pc, -preserve-config	Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.
-q, -quite	Use the option to show the minimum flash progress details.
-i	Option to interactive upgrade (Upgrade only required modules)**
-f, -full	Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade
-ipc, -ignore-platform-check	If this image is for a different platform, this option skips user interaction and continues update process.
-idi,-ignore-diff-image	If this image differs from the currently programmed image, this option skips user interaction and continues update process.
-isi, -ignore-same-image	If this image is same as the currently programmed image, this option skips user interaction and continues update process.
-iml, -ignore-module-location	If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.
-ibv, -ignore-boot-version	If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.
-iri, -ignore -reselect-image	Option skips reselecting the active image.

-inc, -ignore-non-preserve-config	Option skips the restore to default factor setting if the image shares the same configuration area.
-rp, -replace-publickey	Option to replace the Signed Image Key in Existing Firmware.
-vcf, -version-cmp-flash	Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.
-non-interactive	This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-sameimage', '-ignore-module-location' & '-ignoreboot-version' options.
-pXXX, -preserve-XXX	Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask to confirm that those configuration is to be preserved.
-ieo, -ignore-existing-overrides	Clears the existing overrides and preserves only the overrides given in command line if any.
-msp, -split-img	Option to flash the split image.
-f -XXX, -flash-XXX	Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.
-sc, -skip-crc	Option to skip the CRC check
-sf, -skip-fmh	Option to skip the FMH check
-d	Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS
-a, -activate	Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS
-nr, -no-reboot	Option to skip the reboot. With online-flash support, if conf/extlog is not preserved, BMC will still reboot.
-bu, -block-upgrade	Option to Flash using Block by Block method
-netfn <NETFN>	Option to specify AMI OEM Net Function (default 0x32)

[MEDIUM]

-cd	Option to use USB Medium
-nw, -ip, -u, -p, -host, _pa	Option to use Network Medium: 'ip' Option to enter IP, when using Network Medium. 'host' Option to enter host name, When using Network Medium. 'u' Option to enter UserName, When using Network Medium. 'p' Option to enter Password, When using Network Medium. '_p' Option to enter Port Number.
-kcs	Option to use KCS medium.
-serial	Option to use serial interface.
-term	Option to use serial command, e.g. /dev/ttyS0.
-baudrate	Option to use baudrate of the serial terminal, e.g. 115200.

[FW_IMAGE_FILE] Firmware image file name [rom.ima].

-info	Displays information about existing FW and new FW.
-------	--

**NOTE**

-'preserve-config' and '-force-boot' option not be used in interactive upgrade.

*IPv6 Support is added after the tool version 2.7. IPv6 Support can be used with latest Yafuflash tool and firmware, older version of Yafuflash (and/or) firmware will not work.

**Interactive upgrade is not a default option. This option can be enabled in YafuFlash, if it is built with Enable/Disable Interactive Upgrade YafuFlash option selected in Project Configuration file (*.PRJ) using MDS.

Examples for Network Medium

Eg1:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of both existing firmware and new firmware.

Eg2:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware.

Eg3:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -preserve-config
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with preserve config params.

Eg5:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot  
-preserve-config
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg6:

```
./Yafuflash -nw -host spxbmc -force-boot -preserve-config rom.ima
```

Description: This command works with network medium using the host name spxbmc, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg7:

```
./Yafuflash -nw -ip 2000::2005 -force-boot rom.ima
```

Description: This command works with network medium using the ipv6 address 2000::2005, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg8:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -i
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima using interactive upgrade mode and user will be prompt to select the Number of modules and module names to upgrade.

Eg9:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg10:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of existing firmware Version.

Eg11:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey
```

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in firmware.

Eg12:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg13:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg14:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg15:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existingoverrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg16:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg17:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserveconfig
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg18:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 0 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg19:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 1 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg20:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 2 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg21:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 3 rom.ima
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg22:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -quite
```

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima with minimum progress details.

Eg23:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img boot.ima
```

Description: This command works with network medium to flash the boot split image.

Eg24:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img root.ima
```

Description: This command works with network medium to flash the root split image.

Eg25:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -flash-root -flash-conf
```

Description: This command works with network medium to flash root and conf section from rom. ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg26:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin boot.ima -split-img -flash-boot
```

Description: This command works with network medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg27:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with network medium to flash www and osimage from root. ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg28:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -preserve-extlog
```

Description: This command works with network medium to preserve extended log configuration.

Eg29:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -preserve-extlog
```

Description: This command works with network medium to preserve extended log configuration from split image.

Eg30:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 rom.ima
```

Description: This command works with network medium to flash the image on specific peripheral device.

Eg31:

```
./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 root.ima -split-img
```

Description: This command works with network medium to flash the split image on specific peripheral device.

Eg32:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -netfn 0x36
```

Description: This command works with network medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

```

root@localhost:~# ./Yafuflash -nw -ip 10.0.0.120 -u root -p superuser .
./romP.ima
=====
YAFUFlash - Firmware Upgrade Utility (Version 2.1)
=====
(C)Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.0.120...Done
=====
Firmware Details
=====
RomImage      ExistingImage from Flash
-----
Module Name   Description   Version   Module Name   Description   Version
1. boot       BootLoader   9.19      boot          BootLoader   9.19
2. params     ConfigParams 9.19      params        ConfigParams 9.19
3. root       Root         9.19      root          Root         9.19
4. osimage    Linux OS     9.19      osimage       Linux OS     9.19
5. www        Web Pages    9.19      www           Web Pages    9.19
6. cim        Web Pages    9.19      cim           Web Pages    9.19
7. aviator    Web Pages    9.19      aviator       Web Pages    9.19

Existing Image and Current Image are Same
So,Type (Y/y) to do Full Firmware Upgrade or (N/n) to exit
Enter your Option : Y
=====
WARNING!
FIRMWARE UPGRADE MUST NOT BE INTERRUPTED ONCE IT IS STARTED.
PLEASE DO NOT USE THIS FLASH TOOL FROM THE REDIRECTION CONSOLE.
=====
Uploading Firmware Image : 100%... done
Flashing Firmware Image : 100%... done
Verifying Firmware Image : 100%... done
Resetting the firmware.....

```

Screen: If Existing and current images are same

```

root@localhost:~# ./Yafuflash -nw -ip 10.0.0.120 -u root -p superuser ./romP.ima -force-boot
=====
YAFUFlash - Firmware Upgrade Utility (Version 2.1)
=====
(C)Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.0.120...Done
=====
WARNING!
FIRMWARE UPGRADE MUST NOT BE INTERRUPTED ONCE IT IS STARTED.
PLEASE DO NOT USE THIS FLASH TOOL FROM THE REDIRECTION CONSOLE.
=====
Preserving Env Variables... done
Setting Env variables ... done
Upgrading Firmware Image : 100%... done
Resetting the firmware.....
root@localhost:~#

```

Existing and current are different

```

root@muthu Linux_x86_32# ./Yafuflash -nw -ip 10.0.3.5 -u admin -p admin rom.ima -i
=====
YAFUFlash - Firmware Upgrade Utility (Version 2.11)
=====
(C)Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.3.5...Done
=====
Firmware Details
=====
RomImage      ExistingImage from Flash
-----
Module Name   Description   Version   Module Name   Description   Version
1. boot       BootLoader   1.4.00    boot          BootLoader   1.4.00
2. conf       ConfigParams 1.4.00    conf          ConfigParams 1.4.00
3. bkupconf   ConfigParams 1.4.00    bkupconf      ConfigParams 1.4.00
4. root       Root         1.4.00    root          Root         1.4.00
5. osimage    Linux OS     1.4.00    osimage       Linux OS     1.4.00
6. www        Web Pages    1.4.00    www           Web Pages    1.4.00
7. lmedia     Web Pages    1.4.00    lmedia        Web Pages    1.4.00
8. hornet     Web Pages    1.4.00    hornet        Web Pages    1.4.00

For Full Firmware upgrade,Please type (0) alone
For Module Upgrade enter the total no. of Modules to Upgrade
Enter your choice : 4
Enter the Module Name to Update : boot

```

Interactive Upgrade Mode

Examples for USB Medium

Power Save Mode should be disabled for Flashing with Yafu USB Interface.

Eg1:

```
./Yafuflash -cd rom.ima -info
```

Description: This command works with USB medium which displays the details of both Existing Firmware and new firmware.

Eg2:

```
./Yafuflash -cd rom.ima
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware.

Eg3:

```
./Yafuflash -cd rom.ima -force-boot
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -cd rom.ima -preserve-config
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with preserving config params.

Eg5:

```
./Yafuflash -cd rom.ima -force-boot -preserve-config
```

Description: This command works with USB medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade and preserving config params.

Eg6:

```
./Yafuflash -cd rom.ima -i
```

Description: This command works with USB medium, which start to flash the new rom. ima using interactive upgrade mode and user, will be prompt to select the number of modules and module names to upgrade.

Eg7:

```
./Yafuflash -cd -img-section-info
```

Description: This command works with USB medium which displays the details of Existing Firmware.

Eg8:

```
./Yafuflash -cd -img-info
```

Description: This command works with USB medium which displays the details of Existing Firmware Version.

Eg9:

```
./Yafuflash -cd public.pem -replace-publickey
```

Description: This command works with USB medium which replaces the public key in Existing Firmware.

Eg10:

```
./Yafuflash -cd rom.ima -preserve-sel -preserve-ipmi
```

Description: This command works with USB medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11:

```
./Yafuflash -cd rom.ima -preserve-sel -ignore-existing-overrides
```

Description: This command works with USB medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg12:

```
./Yafuflash -cd rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13:

```
./Yafuflash -cd rom.ima -ignore-non-preserve-config
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14:

```
./Yafuflash -cd -img-select 0 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15:

```
./Yafuflash -cd -img-select 1 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16:

```
./Yafuflash -cd -img-select 2 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17:

```
./Yafuflash -cd -img-select 3 rom.ima
```

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18:

```
./Yafuflash -cd rom.ima -quite
```

Description: This command works with USB medium, which start to flash the new rom.ima with minimum progress details.

Eg19:

```
./Yafuflash -cd -split-img boot.ima
```

Description: This command works with USB medium to flash the boot split image.

Eg20:

```
./Yafuflash -cd -split-img root.ima
```

Description: This command works with USB medium to flash the root split image.

Eg21:

```
./Yafuflash -cd -split-img root.ima
```

Description: This command works with USB medium to flash the root split image.

Eg22:

```
./Yafuflash -cd rom.ima -flash-root -flash-conf
```

Description: This command works with USB medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg23:

```
./Yafuflash -cd boot.ima -split-img -flash-boot
```

Description: This command works with USB medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg24:

```
./Yafuflash -cd root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with USB medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg25:

```
./Yafuflash -cd rom.ima -preserve-extlog
```

Description: This command works with USB medium to preserve extended log configuration.

Eg26:

```
./Yafuflash -cd root.ima -split-img -preserve-extlog
```

Description: This command works with USB medium to preserve extended log configuration from split image.

Eg27:

```
./Yafuflash -cd root.ima -d 1 rom.ima
```

Description: This command works with USB medium to flash the image on specific peripheral device.

Eg28:

```
./Yafuflash -cd root.ima -d 1 root.ima -split-img
```

Description: This command works with USB medium to flash the split image on specific peripheral device.

Eg29:

```
./Yafuflash -cd rom.ima -netfn 0x36
```

Description: This command works with USB medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

Examples for KCS Medium

Eg1:

```
./Yafuflash -kcs rom.ima -info
```

Description: This command works with KCS medium which displays the details of both Existing Firmware and new firmware.

Eg2:

```
./Yafuflash -kcs rom.ima
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware.

Eg3:

```
./Yafuflash -kcs rom.ima -force-boot
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4:

```
./Yafuflash -kcs rom.ima -preserve-config
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with preserving config params.

Eg5:

```
./Yafuflash -kcs rom.ima -force-boot -preserve-config
```

Description: This command works with KCS medium which start to flash the new rom. ima to the existing firmware with FORCE BootLoader Upgrade and preserving config params.

Eg6:

```
./Yafuflash -kcs rom.ima -i
```

Description: This command works with KCS medium, which start to flash the new rom. ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7:

```
./Yafuflash -kcs -img-section-info
```

Description: This command works with KCS medium which displays the details of Existing Firmware.

Eg8:

```
./Yafuflash -kcs -img-info
```

Description: This command works with KCS medium which displays the details of Existing Firmware Version.

Eg9:

```
./Yafuflash -kcs public.pem -replace-publickey
```

Description: This command works with KCS medium which replaces the public key in Existing Firmware.

Eg10:

```
./Yafuflash -kcs rom.ima -preserve-sel -preserve-ipmi
```

Description: This command works with KCS medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11:

```
./Yafuflash -kcs rom.ima -preserve-sel -ignore-existing-overrides
```

Description: This command works with KCS medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg12:

```
./Yafuflash -kcs rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13:

```
./Yafuflash -kcs rom.ima -ignore-non-preserve-con
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14:

```
./Yafuflash -kcs -img-select 0 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15:

```
./Yafuflash -kcs -img-select 1 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg17:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info
```

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware Version.

Eg18:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey
```

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in Existing Firmware.

Eg19:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg20:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp
```

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg21:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg22:

```
./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides
```

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg23:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image
```

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg24:

```
./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserve-config
```

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg25:

```
./Yafuflash -kcs -img-select 2 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg26:

```
./Yafuflash -kcs -img-select 3 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg27:

```
./Yafuflash -kcs rom.ima -quite
```

Description: This command works with KCS medium, which start to flash the new rom.ima with minimum progress details.

Eg28:

```
./Yafuflash -kcs -split-img boot.ima
```

Description: This command works with KCS medium to flash the boot split image.

Eg29:

```
./Yafuflash -kcs -split-img root.ima
```

Description: This command works with KCS medium to flash the root split image.

Eg30:

```
./Yafuflash -kcs rom.ima -flash-root -flash-conf
```

Description: This command works with KCS medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg31:

```
./Yafuflash -kcs boot.ima -split-img -flash-boot
```

Description: This command works with KCS medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg32:

```
./Yafuflash -kcs root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with KCS medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg33:

```
./Yafuflash -kcs rom.ima -preserve-extlog
```

Description: This command works with KCS medium to preserve extended log configuration.

Eg34:

```
./Yafuflash -kcs root.ima -split-img -preserve-extlog
```

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg35:

```
./Yafuflash -kcs root.ima -d 1 rom.ima
```

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg36:

```
./Yafuflash -kcs root.ima -d 1 root.ima -split-img
```

Description: This command works with KCS medium to flash the split image on specific peripheral device.

Eg37:

```
./Yafuflash -kcs rom.ima -netfn 0x36
```

Description: This command works with KCS medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32.

4.2.19.1.4 YAFUFlash OS Compatibility

KCS/USB	LAN
Windows Server 2012	Ubuntu 16.04
Windows Server 2008	Windows 8.1
Windows Server 2016 Standard (Exclude Nano Server)	Ubuntu 14.04
Ubuntu Server 16.04	Windows 10
Ubuntu Server 14.04	Fedora 24
RHEL 7.2	
RHEL 6.5	
SLES Server 12.1	
SLES Server 11.4	

4.2.19.1.5 Installation in DOS

1. Copy **Yafuflash.exe** into DOS machine.
2. Run **Yafuflash** utility.
3. Format: **Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE]** where, Perform BMC Flash Update.
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List outs a few examples of the tool

[OPTIONS]

-info	Displays information about existing FW and new FW.
-msi,-img-section-info	Displays information about current FW Sections.
-mi,-img-info	Displays information about current FW Versions.
-fb, -force-boot	Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.
-pc, -preserve-config	Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.
-q, -quite	Use the option to show the minimum flash progress details.
-i	Option to interactive upgrade (Upgrade only required modules)**
-f, -full	Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade
-ipc, -ignore-platform-check	If this image is for a different platform, this option skips user interaction and continues update process.
-idi,-ignore-diff-image	If this image differs from the currently programmed image, this option skips user interaction and continues update process.
-isi, -ignore-same-image	If this image is same as the currently programmed image, this option skips user interaction and continues update process.
-iml, -ignore-module-location	If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.
-ibv, -ignore-boot-version	If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.
-iri, -ignore -reselect-image	Option skips reselecting the active image.
-inc, -ignore-non-preserve-config	Option skips the restore to default factor setting if the image shares the same configuration area.
-rp, -replace-publickey	Option to replace the Signed Image Key in Existing Firmware.
-vcf, -version-cmp-flash	Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.
-non-interactive	This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-same-image', '-ignore-module-location' & '-ignore-boot-version' options.
-pXXX, -preserve-XXX	Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask for the other configuration to be preserved.

-ieo, -ignore-existing-overrides	Clears the existing overrides and preserves only the overrides given in command line if any.
-msp, -split-img	Option to flash the split image.
-f -XXX, -flash-XXX	Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.
-sc, -skip-crc	Option to skip the CRC check
-sf, -skip-fmh	Option to skip the FMH check
-d	Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS
-a, -activate	Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS
-nr, -no-reboot	Option to skip the reboot. With online-flash support, if conf/extlog is not preserved, BMC will still reboot.
-bu, -block-upgrade	Option to Flash using Block by Block method
-netfn <NETFN>	Option to specify AMI OEM Net Function (default 0x32)

[MEDIUM]

-cd	Option to use USB Medium
-nw, -ip, -u, -p, -host, _p	Option to use Network Medium: '-ip' Option to enter IP, when using Network. '-host' Option to enter host name, When using Network Medium. '-u' Option to enter UserName, When using Network Medium. '-p' Option to enter Password, When using Network Medium. '_p' Option to enter Port Number.
-kcs	Option to use KCS medium.

[FW_IMAGE_FILE]

Firmware image file name [rom.ima].

-pe, -preserve-extlog	Option to preserve extlog configuration during firmware flash.
-----------------------	--

Firmware image file name [rom.ima].

**Interactive upgrade is not a default option. This option can be enabled in YafuFlash, if it is built with Enable/Disable Interactive Upgrade YafuFlash option selected in Project Configuration file (*.PRJ) using MDS.

Examples**Eg1:**

```
Yafuflash -kcs -info rom.ima
```

Description: Displays the details of both Existing Firmware and new firmware.

Eg2:

```
Yafuflash -kcs rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware.

Eg3:

```
Yafuflash -kcs -force-boot rom.ima
```

Description: This command starts to flash the new rom.ima to the firmware with FORCE BootLoader upgrade.

Eg4:

```
Yafuflash -kcs -preserve-config rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware with preserving config params.

Eg5:

```
Yafuflash -kcs -force-boot -preserve-config rom.ima
```

Description: This command starts to flash the new rom.ima to the firmware with FORCE BootLoader upgrade and preserving config params.

Eg6:

```
Yafuflash -kcs -i rom.ima
```

Description: This command starts to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the number of modules and module names to upgrade.

Eg7:

```
Yafuflash -kcs -img-section-info
```

Description: Displays the details of Existing Firmware.

Eg8:

```
Yafuflash -kcs -img-info
```

Description: Displays the details of Existing Firmware Version.

Eg9:

```
Yafuflash -kcs public.pem -replace-publickey
```

Description: Replaces the public key in Existing Firmware.

Eg10:

```
Yafuflash -kcs rom.ima -preserve-sdr
```

Description: This command will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg11:

```
Yafuflash -kcs rom.ima -preserve-snmp -preserve-ntp
```

Description: This command will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg12:

```
Yafuflash -kcs rom.ima -preserve-fru -ignore-existing-overrides
```

Description: This command starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg13:

```
Yafuflash -kcs rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides
```

Description: This command starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg14:

```
Yafuflash -kcs -img-select 0 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15:

```
Yafuflash -kcs -img-select 1 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16:

```
Yafuflash -kcs -img-select 2 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17:

```
Yafuflash -kcs -img-select 3 rom.ima
```

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18:

```
Yafuflash -kcs -split-img boot.ima
```

Description: This command works with KCS medium to flash the boot split image.

Eg19:

```
Yafuflash -ksc -split-img root.ima
```

Description: This command works with KCS medium to flash the root split image.

Eg20:

```
Yafuflash -ksc rom.ima -flash-root -flash-conf
```

Description: This command works with KCS medium to flash the root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom. ima.

Eg21:

```
Yafuflash -ksc boot.ima -split-img -flash-boot
```

Description: This command works with KCS medium to flash the root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg22:

```
Yafuflash -ksc root.ima -split-img -flash-www -flash-osimage
```

Description: This command works with KCS medium to flash www and osimage from root. ima split image. --flash-<xxx>, where xxx specifies the modules in root.ima.

Eg23:

```
Yafuflash -ksc rom.ima -preserve-exlog
```

Description: This command works with KCS medium to preserve extended log configuration.

Eg24:

```
Yafuflash -ksc root.ima -split-img -preserve-exlog
```

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg25:

```
Yafuflash -ksc root.ima -d 1 rom.ima
```

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg26:

```
Yafuflash -ksc root.ima -d 1 root.ima -split-img
```

Description: This command works with KCS medium to flash the split image on specific peripheral device.

Eg27:

```
Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -bu root.ima.
```

Description: This command works with network medium to flash the image on specific peripheral device by block by block upgrade.

Eg28:

```
Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -netfn 0x36
```

Description: This command works with network medium to flash the image using 0x36 as AMI OEM Net Function instead of default AMI OEM Netfn 0x32


4.2.20 SOL (Serial Over LAN)

One of the powerful tools in IPMI is Serial Over LAN (SOL) which provides serial line access over the management LAN. The baseboard management controller (BMC) microcontroller embedded on the server motherboard does this by redirecting information destined for the serial port over to the LAN. With SOL console redirection system administrators can remotely view the text-based console on their remote servers from anywhere and perform any task that doesn't require a GUI.

Transporting serial data over IP networks using telnet, serial over IP, SOL and the likes is the way forward for server serial communications. Just as the KVM functions in embedded service processors is displacing the need for external KVM appliances, so the SOL capability of BMCs and console redirection in service processors is reducing the need for serial console servers for server console management.

4.2.21 Enhanced Quick Search support (HTML5 UI Only)

Quick Search is a short-cut for the available menu and sub-menu pages. It displays available search queries. Click (Quick Search) field, and type search terms of the lists in the menu bar. As you type, the suggestions will be displayed in a drop-down list below the Quick Search field as a navigational links of the menu and sub-menu. On selecting your search term from the drop-down list, it will directly go to the specific page which you have searched. Quick Search can be configured under left side Menu bar in the UI. A sample screenshot of Quick Search is shown below.




4.2.22 OTP (One Time Password)

OTP Support for Password Reset

OTP mechanism is used to generate temporary password. Forgot Password option in Login page Web UI can be used to generate OTP which will be sent to already configured e-mail ID. This generated temporary password will be valid for only 5 minutes.

Initial access of Web UI prompts you to enter the User Name and Password. A sample screenshot of the login screen is given below.



Login Page

The fields are explained as follows:

Username: Enter your username in this field.

Password: Enter your password in this field.

Language Selection: Language selection drop-down will be populated based on supported languages in Web UI as a part of multi language support feature. Drop-down option value will be selected based on the browser language. For example, if browser language is configured with Simplified Chinese language (ZH-CN), then option value will be auto selected as China - .

Default language will be selected as US-English if the browser configured language not supported by Web UI. Entire Web UI pages language strings will be displayed based on selected language from drop-down.

Remember Username: Check this option to remember your login Username. If you select this option, the browser will save your credentials internally in its memory, and when you open that site the next time, it will auto-fill Username for you.

Sign me in: After entering the required credentials, click the Sign me in to login to MegaRAC GUI.

I Forgot my Password: If you forget your password, you can generate a new password using this link.

Procedure to Reset Password

1. Enter the Username, and click on Forgot Password link. A pop-up message will prompt you to proceed further, click OK to proceed.

Forgot Password Page

2. Enter **One Time Password (OTP)** sent to your registered Email-ID for changing the password, and click **Submit**.



NOTE

OTP will be expired after 5 minutes.

3. Enter a password in the New Password and Confirm Password fields, and click Submit.
4. Once all the above steps are success, your password will be reset.



NOTE

- Default password should contain minimum of 8 and maximum of 16 alphanumeric characters.
- White space is not allowed.

Chapter 5. Technical Support



www.aicipc.com

Taiwan, Global Headquarters

Address: No. 152, Section 4,
Linghang N. Rd, Dayuan District,
Taoyuan City 337, Taiwan
Tel: +886-3-433-9188
Fax: +886-3-287-1818
Sales Email: sales@aicipc.com.tw
Support Email: support@aicipc.com

Shanghai, China

Address: Room 215, Building 4, No.471
Guiping Road, Xuhui District, Shanghai City,
200233 China
Tel: +86-21-54961421
Sales Email: sales@aicipc.com.cn
Support Email: support@aicipc.com

Moscow, Russia

Address: No.500, 5th Floor, 5th Entrance,
32A, Khoroshevskoye Shosse, Moscow,
123007
Tel: +7-4997019998
Sales Email: support-ru@aicipc.com.tw
Support Email: rma.russia@aicipc.com.tw

North California, United States

Address: 48531 Warm Springs
Boulevard Suite 404 Fremont, CA
94539, United States
Tel: +1-510-573-6730
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

South California, United States

Address: 21808 Garcia Lane
City of Industry, CA 91789,
United States
Toll free: + 1-866-800-0056
Tel: +1-909-895-8989
Fax: +1-909-895-8999
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

New Jersey, United States

Address: 322 Route 46 West Suite 100
Parsippany, NJ 07054 United States
Tel: +1-973-884-8886
Fax: +1-973-884-4794
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

Houten, The Netherlands

Address: Peppelkade 58, 3992AK, Houten,
The Netherlands
Tel: +31-30-6386789
Fax: +31-30-6360638
Sales Email: sales@aicipc.nl
Support Email: support@aicipc.com

For additional technical support or questions about trouble shooting, please contact the AIC® representative nearest to you or visit our AIC® website for more information.
AIC® website: <https://www.aicipc.com/en/faq>.

Appendix

Ports Usage

Port #	Owner Module	Usage
80	Web server(lighttpd)	Listening for network connections on HTTP://
443	Web server(lighttpd)	Listening for secured network connections on HTTPS://
22	SSH	SSH session
623	IPMI	LAN interface
123	NTP	Network Time Protocol (NTP) - used for time synchronization (UDP Connection)
161	SNMP	SNMP listens on this port for incoming SNMP requests. (UDP)
546	DHCPv6	DHCPv6 clients listen for DHCP messages on this port (UDP)